

## **broadcast**

---

**Syntax**    `broadcast forwarding-class-name;`

**Hierarchy Level**    [edit class-of-service multi-destination family ethernet]

**Release Information**    Statement introduced in JUNOS Release 9.5 for EX Series switches.

**Description**    Specify the forwarding class for the broadcast traffic belonging to the Ethernet family.

**Options**    *forwarding-class-name* —Name of the forwarding class:

- `mcast-af`—Default forwarding class for assured forwarding of multicast traffic.
- `mcast-be`—Default best-effort forwarding class for multicast traffic.
- `mcast-ef`—Default forwarding class for expedited forwarding of multicast traffic.

**Required Privilege Level**    routing—To view this statement in the configuration.  
                                     routing-control—To add this statement to the configuration.

- Related Topics**
- Understanding CoS Schedulers
  - Understanding CoS Forwarding Classes
  - Understanding CoS Classifiers

---

Published: 2009-07-22