

## buffer-size

---

<b>Syntax</b>	buffer-size (percent <i>percentage</i>   remainder);
<b>Hierarchy Level</b>	[edit class-of-service schedulers <i>scheduler-name</i> ]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0 for EX Series switches.
<b>Description</b>	Specify buffer size.
<b>Default</b>	If you do not include this statement, the default scheduler transmission rate and buffer size percentages for queues 0 through 7 are 95, 0, 0, 0, 0, 0, 0, and 5 percent.
<b>Options</b>	<p>percent <i>percentage</i> —Buffer size as a percentage of total buffer.</p> <p>remainder—Remaining buffer available.</p>
<b>Required Privilege Level</b>	<p>routing—To view this statement in the configuration.</p> <p>routing-control—To add this statement to the configuration.</p>
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Example: Configuring CoS on EX Series Switches</li><li>■ Defining CoS Schedulers (CLI Procedure) or Defining CoS Schedulers (J-Web Procedure)</li><li>■ Understanding CoS Schedulers</li></ul>

---

Published: 2009-07-22