

class

Syntax `class class-name queue-num queue-number;`

Hierarchy Level [edit class-of-service forwarding-classes]

Release Information Statement introduced in JUNOS Release 9.0 for EX Series switches.

Description Configure up to 16 forwarding classes with multiple forwarding classes mapped to single queues. If you want to configure up to eight forwarding classes with one-to-one mapping to output queues, use the **queue** statement instead of the **class** statement at the [edit class-of-service forwarding-classes] hierarchy level.

Options *class-name* —Name of forwarding class..

queue-num queue-number —Output queue number.

Range: 0 through 15.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

Related Topics ■ Example: Configuring CoS on EX Series Switches
■ Defining CoS Forwarding Classes (CLI Procedure) or Defining CoS Forwarding Classes (J-Web Procedure)
■ Understanding CoS Forwarding Classes

Published: 2009-07-22