

## disable

---

<b>Syntax</b>	disable;
<b>Hierarchy Level</b>	[edit protocols lldp], [edit protocols interface lldp]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0 for EX Series switches.
<b>Description</b>	Disable the LLDP configuration on the switch or on one or more interfaces.
<b>Default</b>	If you do not configure LLDP, it is disabled on the switch and on specific switch interfaces.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ show lldp</li><li>■ Configuring LLDP (CLI Procedure)</li><li>■ Understanding 802.1X and LLDP and LLDP-MED on EX Series Switches</li></ul>

---

Published: 2009-07-21