

dot1q-tunneling

Syntax	dot1q-tunneling { ether-type (0x8100 0x88a8 0x9100); }
Hierarchy Level	[edit ethernet-switching-options]
Release Information	Statement introduced in JUNOS Release 9.3 for EX Series switches. The remaining statement is explained separately.
Description	Set a global value for the Ethertype for Q-in-Q tunneling.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ dot1q-tunneling■ Example: Setting Up Q-in-Q Tunneling on EX Series Switches■ Configuring Q-in-Q Tunneling (CLI Procedure)

Published: 2009-07-22