

forwarding-class

Syntax forwarding-class *class-name* {
 loss-priority *level* {
 code-points [*aliases*] [*6-bit-patterns*];
 }
}

Hierarchy Level [edit class-of-service classifiers (dscp | ieee-802.1 | inet-precedence) *classifier-name*],
[edit class-of-service interfaces *interface-name* unit *logical-unit-number*],
[edit class-of-service rewrite-rules] (dscp | ieee-802.1 | inet-precedence) *rewrite-name*],
[edit class-of-service scheduler-maps *map-name*]

Release Information Statement introduced in JUNOS Release 9.0 for EX Series switches.

Description Define forwarding class name and option values.

Options *class-name* —Name of the forwarding class.

The remaining statements are explained separately.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

Related Topics

- Example: Configuring CoS on EX Series Switches
- Defining CoS Forwarding Classes (CLI Procedure) or Defining CoS Forwarding Classes (J-Web Procedure)
- Understanding CoS Forwarding Classes

Published: 2009-07-22