

## hardware-address

---

<b>Syntax</b>	hardware-address <i>mac-address</i> ;
<b>Hierarchy Level</b>	[edit access address-assignment pool <i>pool-name</i> family inet host <i>hostname</i> ]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0.
<b>Description</b>	Specify the MAC address of the client. This is the hardware address that identifies the client on the network.
<b>Options</b>	<i>mac-address</i> —The MAC address of the client.
<b>Required Privilege Level</b>	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.
<b>Related Topics</b>	■ <a href="#">Configuring Address-Assignment Pools Overview</a>

---

Published: 2009-07-16