

## id

---

<b>Syntax</b>	<code>id id;</code>
<b>Hierarchy Level</b>	[edit virtual-chassis]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.3 for EX Series switches.
<b>Description</b>	Configure the alphanumeric string that identifies a Virtual Chassis configuration.
<b>Options</b>	<i>id</i> —ID of the Virtual Chassis configuration, which uses the ISO family address format—for example, 9622.6ac8.5345.
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Example: Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge</li><li>■ Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge (CLI Procedure)</li><li>■ Understanding Split and Merge in a Virtual Chassis Configuration</li></ul>

---

Published: 2009-07-29