

interface

Syntax interface (all | *interface-name*) {
 bandwidth *bandwidth*;
 no-broadcast;
 no-unknown-unicast;
}

Hierarchy Level [edit ethernet-switching-options storm-control]

Release Information Statement introduced in JUNOS Release 9.1 for EX Series switches.

Description Apply storm control to all interfaces or to the specified interface.

The statements are explained separately.

Default Storm control is enabled on all switch interfaces at a level of 50 percent of the combined broadcast and unknown unicast streams.

Options all—Apply storm control to all interfaces.

interface-name—Apply storm control to the specified interface.

The remaining statements are explained separately.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

Related Topics

- Example: Configuring Storm Control to Prevent Network Outages on EX Series Switches
- Understanding Storm Control on EX Series Switches

Published: 2009-07-28