

level

Syntax level *level*;

Hierarchy Level [edit ethernet-switching-options storm-control interface (all | *interface-name*)]

Release Information Statement introduced in JUNOS Release 9.1 for EX Series switches.
Statement deprecated in JUNOS Release 9.5 for EX Series switches.



NOTE: This statement has been deprecated and might be removed from future product releases. We strongly recommend that you phase out its use and replace it with the bandwidth statement.

Description For interfaces configured for storm control, configure the storm control level as a percentage of the combined broadcast and unknown unicast streams. Any level configuration from 50 to 100 will limit the rate to 50 percent. Also, configuring a level of 0 results in a level of 50 percent.

Default When storm control is enabled on an interface, the storm control level is 50 percent. By default, storm control is enabled for both broadcast and unknown unicast traffic.

Options *level*—Percentage of the combined broadcast and unknown unicast streams.
 Range: 0 through 100 percent
 Default: 50 percent

Required Privilege Level routing—To view this statement in the configuration.
 routing-control—To add this statement to the configuration.

Related Topics ■ Example: Configuring Storm Control to Prevent Network Outages on EX Series Switches
 ■ Understanding Storm Control on EX Series Switches

Published: 2009-07-22