

## max-hops

---

<b>Syntax</b>	max-hops <i>hops</i> ;
<b>Hierarchy Level</b>	[edit protocols mstp]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0 for EX Series switches.
<b>Description</b>	For Multiple Spanning Tree Protocol (MSTP), configure the maximum number of hops a BPDU can be forwarded in the MSTP region.
<b>Default</b>	20 hops
<b>Options</b>	<i>hops</i> — Number of hops the BPDU can be forwarded. <b>Range:</b> 1 through 255 hops <b>Default:</b> 20 hops
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ show spanning-tree bridge</li><li>■ show spanning-tree interface</li><li>■ Example: Configuring Network Regions for VLANs with MSTP on EX Series Switches</li><li>■ Understanding MSTP for EX Series Switches</li></ul>

---

Published: 2009-07-28