

nas-identifier

Syntax	nas-identifier <i>identifier-value</i> ;
Hierarchy Level	[edit access profile <i>profile-name</i> radius options]
Release Information	Statement introduced in JUNOS Release 9.1.
Description	Configure the value for the client RADIUS attribute 32 (NAS-Identifier). This attribute is used for authentication and accounting requests.
Options	<i>identifier-value</i> —A string in the range from 1 through 64 characters.
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.
Related Topics	■ Configuring RADIUS Server Parameters for Subscriber Access

Published: 2009-07-16