

## netbios-node-type

---

<b>Syntax</b>	netbios-node-type <i>node-type</i> ;
<b>Hierarchy Level</b>	[edit access address-assignment pool <i>pool-name</i> family inet dhcp-attributes]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0.
<b>Description</b>	Specify the NetBIOS node type. This is equivalent to DHCP option 46.
<b>Options</b>	<i>node-type</i> —You can specify one of the following node types: <ul style="list-style-type: none"><li>■ b-node—Broadcast node</li><li>■ h-node—Hybrid node</li><li>■ m-node—Mixed node</li><li>■ p-node—Peer-to-peer node</li></ul>
<b>Required Privilege Level</b>	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.
<b>Related Topics</b>	■ <a href="#">Configuring Address-Assignment Pools Overview</a>

---

Published: 2009-07-16