

## no-arp

---

**Syntax** no-arp;

**Hierarchy Level** [edit forwarding-options dhcp-relay overrides],  
[edit forwarding-options dhcp-relay group *group-name* overrides],  
[edit logical-systems *logical-system-name* forwarding-options dhcp-relay overrides],  
[edit logical-systems *logical-system-name* forwarding-options dhcp-relay group *group-name* overrides],  
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* forwarding-options dhcp-relay overrides],  
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* forwarding-options dhcp-relay group *group-name* overrides],  
[edit routing-instances *routing-instance-name* forwarding-options dhcp-relay overrides],  
[edit routing-instances *routing-instance-name* forwarding-options dhcp-relay group *group-name* overrides]

**Release Information** Statement introduced in JUNOS Release 9.3.

**Description** Turn off ARP table population in a distrusted environment.

**Required Privilege Level** interface—To view this statement in the configuration.  
interface-control—To add this statement to the configuration.

**Related Topics**

- Extended DHCP Relay Agent Overview
- Overriding the Default DHCP Relay Configuration

---

Published: 2009-07-16