

no-split-detection

Syntax	no-split-detection;
Hierarchy Level	[edit virtual-chassis]
Release Information	Statement introduced in JUNOS Release 9.3 for EX Series switches.
Description	Disable the split and merge feature in a Virtual Chassis configuration. The split and merge feature is enabled by default on EX4200 switches.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Example: Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge■ Disabling Split and Merge in a Virtual Chassis Configuration (CLI Procedure)■ Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge (CLI Procedure)■ Understanding Split and Merge in a Virtual Chassis Configuration

Published: 2009-07-29