

primary-vlan

Syntax primary-vlan *vlan-name*

Hierarchy Level [edit vlans *vlan-name*]

Release Information Statement introduced in JUNOS Release 9.3 for EX Series switches.
Statement updated with enhanced ? (CLI completion feature) functionality in JUNOS Release 9.5 for EX Series switches.

Description Configure the primary VLAN for this community VLAN. The primary VLAN must be tagged, and the community VLAN must be untagged.



TIP: To display a list of all configured VLANs on the system, including VLANs that are configured but not committed, type ? after **vlan** or **vlans** in your configuration mode command line. Note that only one VLAN is displayed for a VLAN range.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

Related Topics ■ Example: Configuring a Private VLAN on an EX Series Switch
 ■ Creating a Private VLAN (CLI Procedure)

Published: 2009-07-22