

## ranges (Dynamic VLAN)

---

<b>Syntax</b>	<code>ranges (any   <i>low-tag</i>) - (any   <i>high-tag</i>);</code>
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> auto-configure vlan-ranges dynamic-profile (VLAN) <i>profile-name</i> ]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.5.
<b>Description</b>	Configure VLAN ranges for dynamic, auto-sensed VLANs.
<b>Options</b>	<p><code>any</code>—The entire VLAN range.</p> <p><code>low-tag</code>—The lower limit of the VLAN range.</p> <p><code>high-tag</code>—The upper limit of the VLAN range.</p> <p><b>Range:</b> 1 through 4094</p>
<b>Usage Guidelines</b>	See Configuring Single-Level VLAN Ranges for Use with VLAN Dynamic Profiles.
<b>Required Privilege Level</b>	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>

---

Published: 2009-07-16