

## server-group

---

**Syntax**    server-group {  
              server-group-name {  
                  server-ip-address;  
              }  
          }

**Hierarchy Level**    [edit forwarding-options dhcp-relay],  
                          [edit logical-systems *logical-system-name* forwarding-options dhcp-relay],  
                          [edit logical-systems *logical-system-name* routing-instances *routing-instance-name*  
                              forwarding-options dhcp-relay],  
                          [edit routing-instances *routing-instance-name* forwarding-options dhcp-relay]

**Release Information**    Statement introduced in JUNOS Release 8.3.

**Description**    Specify the name of a group of DHCP server addresses for use by the extended DHCP relay agent.

**Options**    *server-group-name*—Name of the group of DHCP server addresses.

*server-ip-address*—IP address of the DHCP server belonging to this named server group. You can configure a maximum of five IP addresses per named server group.

**Required Privilege Level**    interface—To view this statement in the configuration.  
                                  interface-control—To add this statement to the configuration.

**Related Topics**    ■    Extended DHCP Relay Agent Overview

---

Published: 2009-07-16