

write-interval

Syntax	write-interval <i>seconds</i> ;
Hierarchy Level	[edit ethernet-switching-options secure-access-port dhcp-snooping-file]
Release Information	Statement introduced in JUNOS Release 9.4 for EX-series switches.
Description	Specify how frequently the switch writes the database entries from memory into the specified DHCP snooping database file.
Default	None
Options	<i>seconds</i> —Value in seconds. Range: 60 through 86400
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	■ Understanding DHCP Snooping for Port Security on EX Series Switches

Published: 2009-07-23