

Configuring LLDP (J-Web Procedure)

Use the LLDP Configuration page to configure LLDP global and port settings.

To configure LLDP:

1. From the **Configure** menu, select the option **Switching > LLDP**.

The LLDP Configuration page displays LLDP Global Settings and Port Settings.

The second half of the screen displays operational details for the selected port.

2. To modify LLDP Global Settings, click **Global Settings**.

Enter information as described in Table 1.

3. To modify Port Settings, click **Edit** in the Port Settings section.

Enter information as described in Table 2.

Table 1: Global Settings

Field	Function	Your Action
Advertising interval	Specifies the frequency of outbound LLDP advertisements. You can increase or decrease this interval.	Type the number of seconds.
Hold multiplier	Specifies the multiplier factor to be used by an LLDP-enabled switch to calculate the time-to-live (TTL) value for the LLDP advertisements it generates and transmits to LLDP neighbors.	Type the required number in the field.
Fast start count	Specifies the number of LLDP advertisements sent in the first second after the device connects. The default is 3. Increasing this number results in the port initially advertising LLDP-MED at a faster rate for a limited time.	Type the Fast start count.

Table 2: Edit Port Settings

Field	Function	Your Action
LLDP Status	Specifies whether LLDP has been enabled on the port.	Select one: Enabled , Disabled , or None .
LLDP-MED Status	Specifies whether LLDP-MED has been enabled on the port.	Select Enable from the list.

- Related Topics**
- [Configuring LLDP \(CLI Procedure\)](#)
 - [Configuring LLDP-MED \(CLI Procedure\)](#)
 - [Understanding 802.1X and LLDP and LLDP-MED on EX Series Switches](#)