

Configuring Authentication and Accounting Parameters for Subscriber Access

You use an access profile to configure authentication and accounting support for the subscriber access management feature. The access profile enables you to specify the type of methods used for authentication and accounting. You can also configure how subscriber access management collects and uses accounting statistics.

To configure authentication and accounting for subscriber access:

1. Specify the authentication and accounting methods to use.

See [Specifying the Authentication and Accounting Methods for Subscriber Access](#).

2. Specify how accounting statistics are collected.

See [Configuring How Accounting Statistics Are Collected for Subscriber Access](#).

- Related Topics**
- [AAA Service Framework Overview](#)
 - [Configuring Router Interaction with RADIUS Servers](#)
 - [Example: Configuring RADIUS-Based Subscriber Authentication and Accounting](#)

Published: 2009-07-16