

Configuring the VLAN Ethernet Packet Type for Single-Tag VLAN Dynamic Profiles

To configure the VLAN Ethernet packet type the VLAN dynamic profile can accept:

1. Access the interface over which you want to create dynamic VLANs.

```
user@host# edit interfaces ge-0/0/0
```

2. Access the VLAN [auto-configure] hierarchy level.

```
[edit interfaces ge-0/0/0]  
user@host# edit auto-configure
```

3. Access the [vlan-ranges] hierarchy level.

```
[edit interfaces ge-0/0/0 auto-configure]  
user@host# edit vlan-ranges
```

4. Access the VLAN dynamic profile for which you want to configure VLAN ranges.

```
[edit interfaces ge-0/0/0 auto-configure vlan-ranges]  
user@host# edit dynamic-profile (VLAN) VLAN-PROF1
```

5. Specify what VLAN Ethernet packet type the VLAN or stacked VLAN dynamic profile accepts.



NOTE: This release supports only INET (IPv4) Ethernet packet types.

```
[edit interfaces ge-0/0/0 auto-configure vlan-ranges]  
user@host# set accept inet
```

- Related Topics**
- Dynamic 802.1Q VLAN Overview
 - Configuring VLAN Dynamic Profiles
 - Configuring VLAN Interfaces to Use Dynamic Profiles

Published: 2009-07-16