JUNIPER NETWORKS

Junos® OS

Passive Monitoring on Ethernet Interfaces Feature Guide for Routing Devices

Release
14.1

Published: 2014-05-15

Copyright © 2014, Juniper Networks, Inc.

Juniper Networks, Inc.
1194 North Mathilda Avenue
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Junos® OS Passive Monitoring on Ethernet Interfaces Feature Guide for Routing Devices
14.1
Copyright © 2014, Juniper Networks, Inc.
All rights reserved.

The information in this document is current as of the date on the title page.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at http://www.juniper.net/support/eula.html. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Table of Contents

About the Documentation vii
Documentation and Release Notes vii
Supported Platforms vii
Using the Examples in This Manual vii
Merging a Full Example viii
Merging a Snippet viii
Documentation Conventions ix
Documentation Feedback xi
Requesting Technical Support xi
Self-Help Online Tools and Resources xi
Opening a Case with JTAC xii

Part 1 Overview

Chapter 1 **Passive Monitoring on Ethernet Interfaces 3**

Passive Monitoring on Ethernet Interfaces Overview 3

Part 2 Configuration

Chapter 2 **Passive Monitoring on Ethernet Interfaces 7**

Enabling Passive Monitoring on Ethernet Interfaces 7

Chapter 3 **Network Interfaces Configuration Statements and Hierarchy 9**

[edit interfaces] Hierarchy Level 9
[edit logical-systems] Hierarchy Level 25

Chapter 4 **Statement Summary 31**

family 32
fast-aps-switch 36
passive-monitor-mode 37
receive-options-packets 38
receive-ttl-exceeded 38

Part 3 Administration

Chapter 5 **Monitoring Commands 41**

show interfaces (Adaptive Services) 42
show interfaces (Fast Ethernet) 50
show interfaces (Gigabit Ethernet) 66

Copyright © 2014, Juniper Networks, Inc.

Part 4 Troubleshooting

Chapter 6 Ethernet 91

traceroute ethernet 92

Chapter 7 Interface Diagnostics 95

Interface Diagnostics 95
Configuring Loopback Testing 95
Interface Diagnostics 97
Starting and Stopping a BERT Test 101
Example: Configuring Bit Error Rate Testing 101

Part 5 Index

Index 105

Copyright © 2014, Juniper Networks, Inc.

List of Tables

About the Documentation vii

Table 1: Notice Icons ix
Table 2: Text and Syntax Conventions x

Part 3 Administration

Chapter 5 Monitoring Commands 41

Table 3: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields 42
Table 4: show interfaces Fast Ethernet Output Fields 50
Table 5: show interfaces Gigabit Ethernet Output Fields 67
Table 6: Gigabit Ethernet IQ PIC Traffic and MAC Statistics by Interface Type . . . 80

Part 4 Troubleshooting

Chapter 6 Ethernet 91

Table 7: traceroute ethernet Output Fields 92

Chapter 7 Interface Diagnostics 95

Table 8: Loopback Modes by Interface Type 96
Table 9: BERT Capabilities by Interface Type 100

Copyright © 2014, Juniper Networks, Inc.

Copyright © 2014, Juniper Networks, Inc.

About the Documentation

- Documentation and Release Notes on page vii
- Supported Platforms on page vii
- Using the Examples in This Manual on page vii
- Documentation Conventions on page ix
- Documentation Feedback on page xi
- Requesting Technical Support on page xi

Documentation and Release Notes

To obtain the most current version of all Juniper Networks® technical documentation, see the product documentation page on the Juniper Networks website at http://www.juniper.net/techpubs/.

If the information in the latest release notes differs from the information in the documentation, follow the product Release Notes.

Juniper Networks Books publishes books by Juniper Networks engineers and subject matter experts. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration. The current list can be viewed at http://www.juniper.net/books.

Supported Platforms

For the features described in this document, the following platforms are supported:

- M Series
- MX Series
- T Series
- J Series

Using the Examples in This Manual

If you want to use the examples in this manual, you can use the **load merge** or the **load merge relative** command. These commands cause the software to merge the incoming configuration into the current candidate configuration. The example does not become active until you commit the candidate configuration.

Copyright © 2014, Juniper Networks, Inc.

If the example configuration contains the top level of the hierarchy (or multiple hierarchies), the example is a *full example*. In this case, use the **load merge** command.

If the example configuration does not start at the top level of the hierarchy, the example is a *snippet*. In this case, use the **load merge relative** command. These procedures are described in the following sections.

Merging a Full Example

To merge a full example, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration example into a text file, save the file with a name, and copy the file to a directory on your routing platform.

   For example, copy the following configuration to a file and name the file **ex-script.conf**. Copy the **ex-script.conf** file to the **/var/tmp** directory on your routing platform.

   ```
   system {
     scripts {
       commit {
         file ex-script.xsl;
       }
     }
   }
   interfaces {
     fxp0 {
       disable;
       unit 0 {
         family inet {
           address 10.0.0.1/24;
         }
       }
     }
   }
   ```

2. Merge the contents of the file into your routing platform configuration by issuing the **load merge** configuration mode command:

   ```
   [edit]
   user@host# load merge /var/tmp/ex-script.conf
   load complete
   ```

Merging a Snippet

To merge a snippet, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration snippet into a text file, save the file with a name, and copy the file to a directory on your routing platform.

   For example, copy the following snippet to a file and name the file **ex-script-snippet.conf**. Copy the **ex-script-snippet.conf** file to the **/var/tmp** directory on your routing platform.

   ```
   commit {
     file ex-script-snippet.xsl; }
   ```


Copyright © 2014, Juniper Networks, Inc.

2. Move to the hierarchy level that is relevant for this snippet by issuing the following configuration mode command:

   ```
   [edit]
   user@host# edit system scripts
   [edit system scripts]
   ```

3. Merge the contents of the file into your routing platform configuration by issuing the **load merge relative** configuration mode command:

   ```
   [edit system scripts]
   user@host# load merge relative /var/tmp/ex-script-snippet.conf
   load complete
   ```

For more information about the **load** command, see the *CLI User Guide*.

Documentation Conventions

Table 1 on page ix defines notice icons used in this guide.

Table 1: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.
	Tip	Indicates helpful information.
	Best practice	Alerts you to a recommended use or implementation.

Table 2 on page x defines the text and syntax conventions used in this guide.

Copyright © 2014, Juniper Networks, Inc.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
Bold text like this	Represents text that you type.	To enter configuration mode, type the **configure** command: user@host> **configure**
`Fixed-width text like this`	Represents output that appears on the terminal screen.	`user@host>` **show chassis alarms** `No alarms currently active`
Italic text like this	• Introduces or emphasizes important new terms. • Identifies guide names. • Identifies RFC and Internet draft titles.	• A policy *term* is a named structure that defines match conditions and actions. • *Junos OS CLI User Guide* • RFC 1997, *BGP Communities Attribute*
Italic text like this	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name: [edit] root@# **set system domain-name** *domain-name*
Text like this	Represents names of configuration statements, commands, files, and directories; configuration hierarchy levels; or labels on routing platform components.	• To configure a stub area, include the **stub** statement at the **[edit protocols ospf area area-id]** hierarchy level. • The console port is labeled **CONSOLE**.
< > (angle brackets)	Encloses optional keywords or variables.	**stub <default-metric** *metric***>;**
| (pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	**broadcast | multicast** **(*string1* | *string2* | *string3*)**
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	**rsvp { # Required for dynamic MPLS only**
[ ] (square brackets)	Encloses a variable for which you can substitute one or more values.	**community name members [** *community-ids* **]**

Indention and braces ({ })	Identifies a level in the configuration hierarchy.	[edit]
		routing-options {
		  static {
		  route default {
		  nexthop *address*;
		  retain;
		  }
		  }
		}

; (semicolon)	Identifies a leaf statement at a configuration hierarchy level.	

GUI Conventions

Copyright © 2014, Juniper Networks, Inc.

Table 2: Text and Syntax Conventions *(continued)*

Convention	Description	Examples
Bold text like this	Represents graphical user interface (GUI) items you click or select.	• In the Logical Interfaces box, select **All Interfaces**. • To cancel the configuration, click **Cancel**.
> (bold right angle bracket)	Separates levels in a hierarchy of menu selections.	In the configuration editor hierarchy, select **Protocols>Ospf**.

Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can send your comments to techpubs-comments@juniper.net, or fill out the documentation feedback form at https://www.juniper.net/cgi-bin/docbugreport/. If you are using e-mail, be sure to include the following information with your comments:

- Document or topic name
- URL or page number
- Software release version (if applicable)

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf.
- Product warranties—For product warranty information, visit http://www.juniper.net/support/warranty/.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: http://www.juniper.net/customers/support/
- Search for known bugs: http://www2.juniper.net/kb/

Copyright © 2014, Juniper Networks, Inc.

- Find product documentation: http://www.juniper.net/techpubs/
- Find solutions and answer questions using our Knowledge Base: http://kb.juniper.net/
- Download the latest versions of software and review release notes: http://www.juniper.net/customers/csc/software/
- Search technical bulletins for relevant hardware and software notifications: http://kb.juniper.net/InfoCenter/
- Join and participate in the Juniper Networks Community Forum: http://www.juniper.net/company/communities/
- Open a case online in the CSC Case Management tool: http://www.juniper.net/cm/

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: https://tools.juniper.net/SerialNumberEntitlementSearch/

Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at http://www.juniper.net/cm/.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see http://www.juniper.net/support/requesting-support.html.

Copyright © 2014, Juniper Networks, Inc.

PART 1

Overview

- Passive Monitoring on Ethernet Interfaces on page 3

Copyright © 2014, Juniper Networks, Inc.

 Copyright © 2014, Juniper Networks, Inc.

CHAPTER 1

Passive Monitoring on Ethernet Interfaces

- Passive Monitoring on Ethernet Interfaces Overview on page 3

Passive Monitoring on Ethernet Interfaces Overview

The Monitoring Services I and Monitoring Services II PICs are designed to enable IP services. You can monitor IPv4 traffic if you have a Monitoring Services PIC installed in the router with the following PICs:

- 10-port Gigabit Ethernet PIC with SFPs
- 4-port Gigabit Ethernet PIC with SFPs
- 2-port Gigabit Ethernet PIC with SFPs
- 1-port 10-Gigabit Ethernet PIC

NOTE: The PICs in the preceding list support only IPv4.

NOTE: I2.0 based M120 routers and I3.0 based M320 routers with the PICs in the preceding list support passive monitoring starting with Junos OS Release 9.5. Other M Series and T Series routers with the PICs listed above started supporting passive monitoring before Junos OS Release 7.3. Support for 1-port 10-Gigabit Ethernet PIC with XENPAK on I2.0-based M120 routers and I3.0-based M320 routers was added in Junos OS Release 9.5.

- 4-port 10-Gigabit Ethernet LAN/WAN PIC with XFP (T640, T1600, and T4000 Core Routers) (supported on both WAN-PHY and LAN-PHY modes for both IPv4 and IPv6 addresses)

The following interfaces support passive monitoring on the I3.0-based MX 240, MX 480, and MX 960 routers, starting with Junos OS Release 8.5:

- Type 2 MX FPCs
- Type 3 MX FPCs

Copyright © 2014, Juniper Networks, Inc.

- Gigabit Ethernet Enhanced DPC with SFP (DPCE-R-40GE-SFP)
- 4-port 10-Gigabit Ethernet Enhanced DPCs with XFP (DPCE-R-4XGE-XFP)

The following interfaces support passive monitoring on the Trio-based MX 240, MX 480, and MX 960 routers:

- 10-Gigabit Ethernet MPC with SFP+
- 30-Gigabit Ethernet MPC
- 60-Gigabit Ethernet MPC

Passive monitoring is also supported on MX 80 routers with 10-Gigabit Ethernet MPC with SFP+ and 30-Gigabit Ethernet MPC interfaces.

Interfaces configured on the following FPCs and PIC support IPv6 passive monitoring on the T640, T1600, and T4000 routers:

- Enhanced Scaling FPC2
- Enhanced Scaling FPC3
- Enhanced Scaling FPC4
- Enhanced Scaling FPC4.1
- Enhanced II FPC1 (T640 and T1600 routers)
- Enhanced II FPC2 (T640 and T1600 routers)
- Enhanced II FPC3 (T640 and T1600 routers)
- 4-port 10-Gigabit Ethernet LAN/WAN PIC with XFP (supported on both WAN-PHY and LAN-PHY modes for both IPv4 and IPv6 addresses)
- Gigabit Ethernet PIC with SFP
- 10-Gigabit Ethernet PIC with XENPAK (T640 and T1600 routers)
- SONET/SDH OC192/STM64 PICs with XFP (T1600 and T4000 routers)
- SONET/SDH OC48c/STM16 PIC with SFP
- SONET/SDH OC12/STM4 (Multi-Rate) PIC with SFP (T1600 router)
- Type 1 SONET/SDH OC3/STM1 (Multi-Rate) PIC with SFP (T1600 router)

NOTE: Unlike IPv4 passive monitoring, IPv6 passive monitoring is not supported on Monitoring Services PICs. You must configure port mirroring to forward the packets from the passive monitored ports to other interfaces.

Related Documentation

- *Ethernet Interfaces*

Copyright © 2014, Juniper Networks, Inc.

PART 2

Configuration

- Passive Monitoring on Ethernet Interfaces on page 7
- Network Interfaces Configuration Statements and Hierarchy on page 9
- Statement Summary on page 31

Copyright © 2014, Juniper Networks, Inc.

 Copyright © 2014, Juniper Networks, Inc.

CHAPTER 2

Passive Monitoring on Ethernet Interfaces

- Enabling Passive Monitoring on Ethernet Interfaces on page 7

Enabling Passive Monitoring on Ethernet Interfaces

On Ethernet interfaces, enable packet flow monitoring by including the **passive-monitor-mode** statement at the **[edit interfaces *interface-name*]** hierarchy level:

```
[edit interfaces interface-name]
passive-monitor-mode;
```

When you configure an interface in passive monitoring mode, the Packet Forwarding Engine silently drops packets coming from that interface and destined to the router itself. Passive monitoring mode also stops the Routing Engine from transmitting any packet from that interface. Packets received from the monitored interface can be forwarded to monitoring interfaces. If you include the **passive-monitor-mode** statement in the configuration:

- Gigabit and Fast Ethernet interfaces can support both per-port passive monitoring and per-VLAN passive monitoring. The destination MAC filter on the receive port of the Ethernet interfaces is disabled.
- Ethernet encapsulation options are not allowed.
- Ethernet interfaces do not support the **stacked-vlan-tagging** statement for both IPv4 and IPv6 packets in passive monitor mode.

For IPv4 monitoring services interfaces, enable packet flow monitoring by including the **family** statement at the **[edit interfaces mo-*fpc/pic/port* unit *logical-unit-number*]** hierarchy level, specifying the **inet** option:

```
[edit interfaces mo-fpc/pic/port unit logical-unit-number]
family inet;
```

For conformity with the cflowd record structure, you must include the **receive-options-packets** and **receive-ttl-exceeded** statements at the **[edit interfaces mo-*fpc/pic/port* unit *logical-unit-number* family inet]** hierarchy level:

```
[edit interfaces mo-fpc/pic/port unit logical-unit-number family inet]
receive-options-packets;
receive-ttl-exceeded;
```

Copyright © 2014, Juniper Networks, Inc.

IPv6 passive monitoring is not supported on monitoring services PICs. A user must configure port mirroring to forward the packets from the passive monitored ports to other interfaces.

For information on FPCs and PICs that support IPv6 passive monitoring on the T640, T1600, and T4000 routers, see "Passive Monitoring on Ethernet Interfaces Overview" on page 3. Interfaces configured on these FPCs and PICs support IPv6 passive monitoring.

To configure port mirroring, include the **port-mirroring** statement at the **[edit forwarding-options]** hierarchy level.

For the monitoring services interface, you can configure multiservice physical interface properties. For more information, see *Configuring Multiservice Physical Interface Properties* and the *Junos OS Services Interfaces Library for Routing Devices*.

Related Documentation

- Passive Monitoring on Ethernet Interfaces Overview on page 3
- *Configuring Multiservice Physical Interface Properties*
- *Junos OS Services Interfaces Library for Routing Devices*
- *Ethernet Interfaces*

Copyright © 2014, Juniper Networks, Inc.

CHAPTER 3

Network Interfaces Configuration Statements and Hierarchy

- [edit interfaces] Hierarchy Level on page 9
- [edit logical-systems] Hierarchy Level on page 25

[edit interfaces] Hierarchy Level

The statements at the **[edit interfaces *interface-name* unit *logical-unit-number*]** hierarchy level can also be configured at the **[edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]** hierarchy level.

NOTE: The *accounting-profile* statement is an exception to this rule. The accounting-profile statement can be configured at the [edit interfaces *interface-name* unit *logical-unit-number*] hierarchy level, but it cannot be configured at the [edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*] hierarchy level.

```
interfaces {
    traceoptions {
        file filename <files number> <match regular-expression> <size size> <world-readable |
            no-world-readable> ;
        flag flag <disable>;
    }
    interface-name {
        accounting-profile name;
        aggregated-ether-options {
            (flow-control | no-flow-control);
            lacp {
                (active | passive);
                link-protection {
                    disable;
                (revertive | non-revertive);
                periodic interval;
                system-priority priority;
            }
            link-protection;
            link-speed speed;
```

Copyright © 2014, Juniper Networks, Inc.

```
    (loopback | no-loopback);
    mc-ae{
      chassis-id chassis-id;
      mc-ae-id mc-ae-id;
      mode (active-active | active-standby);
      redundancy-group group-id;
      status-control (active | standby);
    }
    minimum-links number;
    source-address-filter {
      mac-address;
    }
    (source-filtering | no-source-filtering);
  }
  shared-scheduler;
  aggregated-sonet-options {
    link-speed speed | mixed;
    minimum-links number;
  }
  atm-options {
    cell-bundle-size cells;
    ilmi;
    linear-red-profiles profile-name {
      high-plp-max-threshold percent;
      low-plp-max-threshold percent;
      queue-depth cells high-plp-threshold percent low-plp-threshold percent;
    }
    mpls {
      pop-all-labels {
        required-depth number;
      }
    }
    pic-type (atm1 | atm2);
    plp-to-clp;
    promiscuous-mode {
      vpi vpi-identifier;
    }
    scheduler-maps map-name {
      forwarding-class class-name {
        epd-threshold cells plp1 cells;
        linear-red-profile profile-name;
        priority (high | low);
        transmit-weight (cells number | percent number);
      }
      vc-cos-mode (alternate | strict);
    }
    use-null-cw;
      vpi vpi-identifier {
      maximum-vcs maximum-vcs;
      oam-liveness {
        down-count cells;
        up-count cells;
      }
      oam-period (seconds | disable);
      shaping {
```

 Copyright © 2014, Juniper Networks, Inc.

```
            (cbr rate | rtvbr peak rate sustained rate burst length | vbr peak rate sustained rate
              burst length);
            queue-length number;
          }
        }
      }
      clocking clock-source;
      damping {
        enable;
        half-life seconds;
        max-suppress seconds;
        reuse number;
        suppress number;
      }
      data-input (system | interface interface-name);
      dce;
      serial-options {
        clock-rate rate;
        clocking-mode (dce | internal | loop);
        control-polarity (negative | positive);
        cts-polarity (negative | positive);
        dcd-polarity (negative | positive);
        dce-options {
          control-signal (assert | de-assert | normal);
          cts (ignore | normal | require);
          dcd (ignore | normal | require);
          dsr (ignore | normal | require);
          dtr signal-handling-option;
          ignore-all;
          indication (ignore | normal | require);
          rts (assert | de-assert | normal);
          tm (ignore | normal | require);
        }
        dsr-polarity (negative | positive);
        dte-options {
          control-signal (assert | de-assert | normal);
          cts (ignore | normal | require);
          dcd (ignore | normal | require);
          dsr (ignore | normal | require);
          dtr signal-handling-option;
          ignore-all;
          indication (ignore | normal | require);
          rts (assert | de-assert | normal);
          tm (ignore | normal | require);
        }
        dtr-circuit (balanced | unbalanced);
        dtr-polarity (negative | positive);
        encoding (nrz | nrzi);
        indication-polarity (negative | positive);
        line-protocol protocol;
        loopback mode;
        rts-polarity (negative | positive);
        tm-polarity (negative | positive);
        transmit-clock invert;
      }
      description text;
```

Copyright © 2014, Juniper Networks, Inc.

```
alias alias-name;
dialer-options {
   pool pool-name <priority priority>;
}
disable;
ds0-options {
   bert-algorithm algorithm;
   bert-error-rate rate;
   bert-period seconds;
   byte-encoding (nx56 | nx64);
   fcs (16 | 32);
   idle-cycle-flag (flags | ones);
   invert-data;
   loopback payload;
   start-end-flag (filler | shared);
}
e1-options {
   bert-error-rate rate;
   bert-period seconds;
   fcs (16 | 32);
   framing (g704 | g704-no-crc4 | unframed);
   idle-cycle-flag (flags | ones);
   invert-data;
   loopback (local | remote);
   start-end-flag (filler | shared);
   timeslots time-slot-range;
}
e3-options {
   atm-encapsulation (direct | plcp);
   bert-algorithm algorithm;
   bert-error-rate rate;
   bert-period seconds;
   framing feet;
   compatibility-mode (digital-link | kentrox | larscom) <subrate value>;
   fcs (16 | 32);
   framing (g.751 | g.832);
   idle-cycle-flag (filler | shared);
   invert-data;
   loopback (local | remote);
   (payload-scrambler | no-payload-scrambler);
   start-end-flag (filler | shared);
   (unframed | no-unframed);
}
encapsulation type;
es-options {
   backup-interface es-fpc/pic/port;
}
fastether-options {
   802.3ad aex;
   (flow-control | no-flow-control);
   ignore-l3-incompletes;
   ingress-rate-limit rate;
   (loopback | no-loopback);
   mpls {
      pop-all-labels {
         required-depth number;
```

 Copyright © 2014, Juniper Networks, Inc.

```
      }
    }
    source-address-filter {
      mac-address;
    }
    (source-filtering | no-source-filtering);
  }
  flexible-vlan-tagging;
  gigether-options {
    802.3ad aex;
    (asynchronous-notification | no-asynchronous-notification);
    (auto-negotiation | no-auto-negotiation) remote-fault <local-interface-online |
      local-interface-offline>;
    auto-reconnect seconds;
    (flow-control | no-flow-control);
    ignore-l3-incompletes;
    (loopback | no-loopback);
    mpls {
      pop-all-labels {
        required-depth number;
      }
    }
    no-auto-mdix;
    source-address-filter {
      mac-address;
    }
    (source-filtering | no-source-filtering);
    ethernet-switch-profile {
      (mac-learn-enable | no-mac-learn-enable);
      tag-protocol-id [ tpids ];
      ethernet-policer-profile {
        input-priority-map {
          ieee802.1p premium [ values ];
        }
        output-priority-map {
          classifier {
            premium {
              forwarding-class class-name {
                loss-priority (high | low);
              }
            }
          }
        }
        policer cos-policer-name {
          aggregate {
            bandwidth-limit bps;
            burst-size-limit bytes;
          }
          premium {
            bandwidth-limit bps;
            burst-size-limit bytes;
          }
        }
      }
    }
  }
```

Copyright © 2014, Juniper Networks, Inc.

```
(gratuitous-arp-reply | no-gratuitous-arp-reply);
hold-time up milliseconds down milliseconds;
ima-group-options {
  differential-delay number;
  frame-length (32 | 64 | 128 | 256);
  frame-synchronization {
    alpha number;
    beta number;
    gamma number;
  }
  minimum-links number;
  symmetry (symmetrical-config-and-operation |
    symmetrical-config-asymmetrical-operation);
  test-procedure {
    ima-test-start;
    ima-test-stop;
    interface name;
    pattern number;
    period number;
  }
  transmit-clock (common | independent);
  version (1.0 |1.1);
}
ima-link-options group-id group-id;
interface-set interface-set-name {
  interface ethernet-interface-name {
    (unit unit-number | vlan-tags-outer vlan-tag);
  }
  interface interface-name {
    (unit unit-number);
  }
}
isdn-options {
  bchannel-allocation (ascending | descending);
  calling-number number;
  pool pool-name <priority priority>;
  spid1 spid-string;
  spid2 spid-string;
  static-tei-val value;
  switch-type (att5e | etsi | ni1 | ntdms100 | ntt);
  t310 seconds;
  tei-option (first-call | power-up);
}
keepalives <down-count number> <interval seconds> <up-count number>;
link-mode mode;
lmi {
  lmi-type (ansi | itu | c-lmi);
  n391dte number;
  n392dce number;
  n392dte number;
  n393dce number;
  n393dte number;
  t391dte seconds;
  t392dce seconds;
}
lsq-failure-options {
```


Copyright © 2014, Juniper Networks, Inc.

```
    no-termination-request;
    [ trigger-link-failure interface-name ];
  }
  mac mac-address;
  mlfr-uni-nni-bundle-options {
    acknowledge-retries number;
    acknowledge-timer milliseconds;
    action-red-differential-delay (disable-tx | remove-link);
    drop-timeout milliseconds;
    fragment-threshold bytes;
    cisco-interoperability send-lip-remove-link-for-link-reject;
    hello-timer milliseconds;
    link-layer-overhead percent;
    lmi-type (ansi | itu | c-lmi);
    minimum-links number;
    mrru bytes;
    n391 number;
    n392 number;
    n393 number;
    red-differential-delay milliseconds;
    t391 seconds;
    t392 seconds;
    yellow-differential-delay milliseconds;
  }
  modem-options {
    dialin (console | routable);
    init-command-string initialization-command-string;
  }
  mtu bytes;
  multi-chassis-protection {
    peer a.b.c.d {
      interfaceinterface-name;
      }
    }
  multiservice-options {
    (core-dump | no-core-dump);
    (syslog | no-syslog);
  }
  native-vlan-id number;
  no-gratuitous-arp-request;
  no-keepalives;
  no-partition {
    interface-type type;
  }
  no-vpivci-swapping;
  otn-options {
    fec (efec | gfec | none);
    (laser-enable | no-laser-enable);
    (line-loopback | no-line-loopback);
    pass-thru;
    rate (fixed-stuff-bytes | no-fixed-stuff-bytes | pass-thru);
    transmit-payload-type number;
    trigger (oc-lof | oc-lom | oc-los | oc-wavelength-lock | odu-ais | odu-bbe-th | odu-bdi
      | odu-es-th | odu-lck | odu-oci | odu-sd | odu-ses-th | odu-ttim | odu-uas-th |
      opu-ptm | otu-ais | otu-bbe-th | otu-bdi | otu-es-th | otu-fec-deg | otu-fec-exe |
      otu-iae | otu-sd | otu-ses-th | otu-ttim | otu-uas-th);
```

Copyright © 2014, Juniper Networks, Inc.

```
    tti;
}
optics-options {
    wavelength nm;
    alarm alarm-name {
        (syslog | link-down);
    }
    warning warning-name {
        (syslog | link-down);
    }
}
partition partition-number oc-slice oc-slice-range interface-type type;
timeslots time-slot-range;
passive-monitor-mode;
per-unit-scheduler;
ppp-options {
    chap {
        access-profile name;
        default-chap-secret name;
        local-name name;
        passive;
    }
    compression {
        acfc;
        pfc;
    }
    dynamic-profile profile-name;
    no-termination-request;
    pap {
        access-profile name;
        local-name name;
        local-password password;
        compression;
    }
}
psn-vcipsn-vci-identifier;
psn-vpipsn-vpi-identifier;
receive-bucket {
    overflow (discard | tag);
    rate percentage;
    threshold bytes;
}
redundancy-options {
    priority sp-fpc/pic/port;
    secondary sp-fpc/pic/port;
    hot-standby;
}
satop-options {
    payload-size n;
}
schedulers number;
serial-options {
    clock-rate rate;
    clocking-mode (dce | internal | loop);
    control-polarity (negative | positive);
    cts-polarity (negative | positive);
```


Copyright © 2014, Juniper Networks, Inc.

```
    dcd-polarity (negative | positive);
    dce-options {
      control-signal (assert | de-assert | normal);
      cts (ignore | normal | require);
      dcd (ignore | normal | require);
      dsr (ignore | normal | require);
      dtr signal-handling-option;
      ignore-all;
      indication (ignore | normal | require);
      rts (assert | de-assert | normal);
      tm (ignore | normal | require);
    }
    dsr-polarity (negative | positive);
    dte-options {
      control-signal (assert | de-assert | normal);
      cts (ignore | normal | require);
      dcd (ignore | normal | require);
      dsr (ignore | normal | require);
      dtr signal-handling-option;
      ignore-all;
      indication (ignore | normal | require);
      rts (assert | de-assert | normal);
      tm (ignore | normal | require);
    }
    dtr-circuit (balanced | unbalanced);
    dtr-polarity (negative | positive);
    encoding (nrz | nrzi);
    indication-polarity (negative | positive);
    line-protocol protocol;
    loopback mode;
    rts-polarity (negative | positive);
    tm-polarity (negative | positive);
    transmit-clock invert;
  }
  services-options {
    inactivity-timeout seconds;
    open-timeout seconds;
    session-limit {
      maximum number;
      rate new-sessions-per-second;
      }
      syslog {
      host hostname {
        facility-override facility-name;
        log-prefix prefix-number;
        services priority-level;
      }
    }
  }
  shdsl-options {
    annex (annex-a | annex-b);
    line-rate line-rate;
    loopback (local | remote);
    snr-margin {
      current margin;
      snext margin;
```

```
    }
  }
  sonet-options {
    aggregate asx;
    aps {
      advertise-interval milliseconds;
      annex-b;
      authentication-key key;
      fast-aps-switch;
      force;
      hold-time milliseconds;
      lockout;
      neighbor address;
      paired-group group-name;
      preserve-interface;
      protect-circuit group-name;
      request;
      revert-time seconds;
      switching-mode (bidirectional | unidirectional);
      working-circuit group-name;
    }
    bytes {
      c2 value;
      e1-quiet value;
      f1 value;
      f2 value;
      s1 value;
      z3 value;
      z4 value;
    }
    fcs (16 | 32);
    loopback (local | remote);
    mpls {
      pop-all-labels {
        required-depth number;
      }
    }
    path-trace trace-string;
    (payload-scrambler | no-payload-scrambler);
    rfc-2615;
    trigger {
      defect ignore;
      hold-time up milliseconds down milliseconds;
    }
    vtmapping (itu-t | klm);
    (z0-increment | no-z0-increment);
  }
  speed (10m | 100m | 1g | oc3 | oc12 | oc48);
  stacked-vlan-tagging;
  switch-options {
    switch-port port-number {
      (auto-negotiation | no-auto-negotiation);
      speed (10m | 100m | 1g);
      link-mode (full-duplex | half-duplex);
    }
  }
```


Copyright © 2014, Juniper Networks, Inc.

```
t1-options {
  bert-algorithm algorithm;
  bert-error-rate rate;
  bert-period seconds;
  buildout value;
  byte-encoding (nx56 | nx64);
  crc-major-alarm-threshold (1e-3 | 5e-4 | 1e-4 | 5e-5 | 1e-5);
  crc-minor-alarm-threshold (1e-3 | 5e-4 | 1e-4 | 5e-5 | 1e-5 | 5e-6 | 1e-6);
  fcs (16 | 32);
  framing (esf | sf);
  idle-cycle-flag (flags | ones);
  invert-data;
  line-encoding (ami | b8zs);
  loopback (local | payload | remote);
  remote-loopback-respond;
  start-end-flag (filler | shared);
  timeslots time-slot-range;
}
t3-options {
  atm-encapsulation (direct | plcp);
  bert-algorithm algorithm;
  bert-error-rate rate;
  bert-period seconds;
  buildout feet;
  (cbit-parity | no-cbit-parity);
  compatibility-mode (adtran | digital-link | kentrox | larscom | verilink) <subrate
    value>;
  fcs (16 | 32);
  (feac-loop-respond | no-feac-loop-respond);
  idle-cycle-flag value;
  (long-buildout | no-long-buildout);
  (loop-timing | no-loop-timing);
  loopback (local | payload | remote);
  (mac | no-mac);
  (payload-scrambler | no-payload-scrambler);
  start-end-flag (filler | shared);
}
traceoptions {
  flag flag <flag-modifier> <disable>;
}
transmit-bucket {
  overflow discard;
  rate percentage;
  threshold bytes;
}
(traps | no-traps);
unidirectional;
vlan-tagging;
vlan-vci-tagging;
unit logical-unit-number {
  accept-source-mac {
    mac-address mac-address {
      policer {
        input cos-policer-name;
        output cos-policer-name;
      }
```

Copyright © 2014, Juniper Networks, Inc.

```
    }
  }
  accounting-profile name;
  advisory-options {
    downstream-rate rate;
    upstream-rate rate;
  }
  allow-any-vci;
  atm-scheduler-map (map-name | default);
  backup-options {
    interface interface-name;
  }
  bandwidth rate;
  cell-bundle-size cells;
  clear-dont-fragment-bit;
  compression {
    rtp {
      f-max-period number;
      maximum-contexts number <force>;
      queues [ queue-numbers ];
      port {
        minimum port-number;
        maximum port-number;
      }
    }
  }
  compression-device interface-name;
  copy-tos-to-outer-ip-header;
  demux-destination family;
  demux-source family;
  demux-options {
    underlying-interface interface-name;
  }
  description text;
  alias alias-name;
  interface {
    l2tp-interface-id name;
    (dedicated | shared);
  }
  dialer-options {
    activation-delay seconds;
    callback;
    callback-wait-period time;
    deactivation-delay seconds;
    dial-string [ dial-string-numbers ];
    idle-timeout seconds;
    incoming-map {
      caller (caller-id | accept-all);
      initial-route-check seconds;
      load-interval seconds;
      load-threshold percent;
      pool pool-name;
      redial-delay time;
      watch-list {
        [ routes ];
      }
```

 Copyright © 2014, Juniper Networks, Inc.

```
    }
  }
  disable;
  disable-mlppp-inner-ppp-pfc;
  dlci dlci-identifier;
  drop-timeout milliseconds;
  dynamic-call-admission-control {
    activation-priority priority;
    bearer-bandwidth-limit kilobits-per-second;
  }
  encapsulation type;
  epd-threshold cells plp1 cells;
  fragment-threshold bytes;
  inner-vlan-id-range start start-id end end-id;
  input-vlan-map {
    (pop | pop-pop | pop-swap | push | push-push | swap | swap-push | swap-swap);
    inner-tag-protocol-id tpid;
    inner-vlan-id number;
    tag-protocol-id tpid;
    vlan-id number;
  }
  interleave-fragments;
  inverse-arp;
  layer2-policer {
    input-policer policer-name;
    input-three-color policer-name;
    output-policer policer-name;
    output-three-color policer-name;
  }
  link-layer-overhead percent;
  minimum-links number;
  mrru bytes;
  multicast-dlci dlci-identifier;
  multicast-vci vpi-identifier.vci-identifier;
  multilink-max-classes number;
  multipoint;
  oam-liveness {
    down-count cells;
    up-count cells;
  }
  oam-period (seconds | disable);
  output-vlan-map {
    (pop | pop-pop | pop-swap | push | push-push | swap | swap-push | swap-swap);
    inner-tag-protocol-id tpid;
    inner-vlan-id number;
    tag-protocol-id tpid;
    vlan-id number;
  }
  passive-monitor-mode;
  peer-unit unit-number;
  plp-to-clp;
  point-to-point;
  ppp-options {
    chap {
      access-profile name;
      default-chap-secret name;
```

```
        local-name name;
        passive;
    }
    compression {
        acfc;
        pfc;
        pap;
        default-pap-password password;
        local-name name;
        local-password password;
        passive;
    }
    dynamic-profile profile-name;
    lcp-max-conf-req number;
    lcp-restart-timer milliseconds;
    loopback-clear-timer seconds;
    ncp-max-conf-req number;
    ncp-restart-timer milliseconds;
}
pppoe-options {
    access-concentrator name;
    auto-reconnect seconds;
    (client | server);
    service-name name;
    underlying-interface interface-name;
}
proxy-arp;
service-domain (inside | outside);
shaping {
    (cbr rate | rtvbr peak rate sustained rate burst length | vbr peak rate sustained rate
        burst length);
    queue-length number;
}
short-sequence;
transmit-weight number;
(traps | no-traps);
trunk-bandwidth rate;
trunk-id number;
tunnel {
    backup-destination address;
    destination address;
    key number;
    routing-instance {
        destination routing-instance-name;
    }
    source source-address;
    ttl number;
}
vci vpi-identifier.vci-identifier;
vci-range start start-vci end end-vci;
vpi vpi-identifier;
vlan-id number;
vlan-id-list [vlan-id vlan-id–vlan-id];
vlan-id-range number-number;
vlan-tags inner tpid.vlan-id outer tpid.vlan-id;
vlan-tags-outer tpid.vlan-id inner-list [vlan-id vlan-id–vlan-id];
```


Copyright © 2014, Juniper Networks, Inc.

```
family family {
  accounting {
    destination-class-usage;
    source-class-usage {
      direction;
    }
  }
  access-concentrator name;
  address address {
    destination address;
  }
  bundle ml-fpc/pic/port | ls-fpc/pic/port);
  direct-connect;
  duplicate-protection;
  dynamic-profile profile-name;
  filter {
    group filter-group-number;
    input filter-name;
    input-list {
      [ filter-names ];
      output filter-name;
    }
    output-list {
      [ filter-names ];
    }
  }
  ipsec-sa sa-name;
  keep-address-and-control;
  max-sessions number;
  max-sessions-vsa-ignore;
  mtu bytes;
  multicast-only;
  negotiate-address;
  no-redirects;
  policer {
    arp policer-template-name;
    disable-arp-policer
    input policer-template-name;
    output policer-template-name;
  }
  primary;
  proxy inet-address address;
  receive-options-packets;
  receive-ttl-exceeded;
  remote (inet-address address | mac-address address);
  rpf-check {
    fail-filter filter-name;
    mode loose;
  }
  sampling {
    direction;
  }
  service {
    input {
      service-set service-set-name <service-filter filter-name>;
      post-service-filter filter-name;
```

Copyright © 2014, Juniper Networks, Inc.

```
    }
    output {
      service-set service-set-names <service-filter filter-name>;
    }
  }
  service-name-table table-name;
  short-cycle-protection <lockout-time-min minimum-seconds lockout-time-max
    maximum-seconds>;
  targeted-broadcast {
    forward-and-send-to-re;
    forward-only;
  }
  (translate-discard-eligible | no-translate-discard-eligible);
  (translate-fecn-and-becn | no-translate-fecn-and-becn);
  translate-plp-control-word-de;
  unnumbered-address interface-name <destination address destination-profile
    profile-name | preferred-source-address address>;
  address address {
    arp ip-address (mac | multicast-mac) mac-address <publish>;
    broadcast address;
    destination address;
    destination-profile name;
    eui-64;
    multipoint-destination address (dlci dlci-identifier | vci vci-identifier);
    multipoint-destination address {
      epd-threshold cells plp1 cells;
      inverse-arp;
      oam-liveness {
        up-count cells;
        down-count cells;
      }
      oam-period (seconds | disable);
      shaping {
        (cbr rate | rtvbr peak rate sustained rate burst length | vbr peak rate sustained
          rate burst length);
        queue-length number;
      }
      vci vpi-identifier.vci-identifier;
    }
    preferred;
    primary;
    (vrrp-group | vrrp-inet6-group) group-number {
      (accept-data | no-accept-data);
      advertise–interval seconds;
      authentication-type authentication;
      authentication-key key;
      fast-interval milliseconds;
      (preempt | no-preempt) {
        hold-time seconds;
      }
      priority-number number;
      track {
        priority-cost seconds;
        priority-hold-time interface-name {
          bandwidth-threshold bits-per-second {
            priority;
```


Copyright © 2014, Juniper Networks, Inc.

```
                    }
                    interface priority;
                  }
                  route ip-address/mask routing-instance instance-name priority-cost cost;
                }
                virtual-address [ addresses ];
              }
            }
          }
        }
      }
    }
```

Related Documentation

- *Junos OS Hierarchy and RFC Reference*
- *Ethernet Interfaces*
- *Junos OS Network Interfaces Library for Routing Devices*

[edit logical-systems] Hierarchy Level

The following lists the statements that can be configured at the **[edit logical-systems]** hierarchy level that are also documented in this manual. For more information about logical systems, see the *Logical Systems Feature Guide for Routing Devices*.

```
logical-systems logical-system-name {
  interfaces interface-name {
    unit logical-unit-number {
      accept-source-mac {
        mac-address mac-address {
          policer {
            input cos-policer-name;
            output cos-policer-name;
          }
        }
      }
      allow-any-vci;
      atm-scheduler-map (map-name | default);
      bandwidth rate;
      backup-options {
        interface interface-name;
      }
      cell-bundle-size cells;
      clear-dont-fragment-bit;
      compression {
        rtp {
          f-max-period number;
          port {
            minimum port-number;
            maximum port-number;
          }
          queues [ queue-numbers ];
        }
      }
      compression-device interface-name;
```

```
description text;
interface {
  l2tp-interface-id name;
  (dedicated | shared);
}
dialer-options {
  activation-delay seconds;
  deactivation-delay seconds;
  dial-string [ dial-string-numbers ];
  idle-timeout seconds;
  initial-route-check seconds;
  load-threshold number;
  pool pool;
  remote-name remote-callers;
  watch-list {
    [ routes ];
  }
}
disable;
dlci dlci-identifier;
drop-timeout milliseconds;
dynamic-call-admission-control {
  activation-priority priority;
  bearer-bandwidth-limit kilobits-per-second;
}
encapsulation type;
epd-threshold cells plp1 cells;
fragment-threshold bytes;
input-vlan-map {
  inner-tag-protocol-id;
  inner-vlan-id;
  (pop | pop-pop | pop-swap | push | push-push | swap | swap-push | swap-swap);
  tag-protocol-id tpid;
  vlan-id number;
}
interleave-fragments;
inverse-arp;
layer2-policer {
  input-policer policer-name;
  input-three-color policer-name;
  output-policer policer-name;
  output-three-color policer-name;
}
link-layer-overhead percent;
minimum-links number;
mrru bytes;
multicast-dlci dlci-identifier;
multicast-vci vpi-identifier.vci-identifier;
multilink-max-classes number;
multipoint;
oam-liveness {
  up-count cells;
  down-count cells;
}
oam-period (seconds | disable);
output-vlan-map {
```


Copyright © 2014, Juniper Networks, Inc.

```
    inner-tag-protocol-id;
    inner-vlan-id;
    (pop | pop-pop | pop-swap | push | push-push | swap | swap-swap);
    tag-protocol-id tpid;
    vlan-id number;
  }
  passive-monitor-mode;
  peer-unit unit-number;
  plp-to-clp;
  point-to-point;
  ppp-options {
    chap {
      access-profile name;
      default-chap-secret name;
      local-name name;
      passive;
    }
    compression {
      acfc;
      pfc;
      }
    }
    dynamic-profile profile-name;
    pap {
      default-pap-password password;
      local-name name;
      local-password password;
      passive;
    }
  }
  proxy-arp;
  service-domain (inside | outside);
  shaping {
    (cbr rate | rtvbr peak rate sustained rate burst length | vbr peak rate sustained rate
      burst length);
    queue-length number;
  }
  short-sequence;
  transmit-weight number;
  (traps | no-traps);
  trunk-bandwidth rate;
  trunk-id number;
  tunnel {
    backup-destination address;
    destination address;
    key number;
    routing-instance {
      destination routing-instance-name;
    }
    source source-address;
    ttl number;
  }
  vci vpi-identifier.vci-identifier;
  vlan-id number;
  vlan-id-list [vlan-id vlan-id–vlan-id]
  vlan-tags inner tpid.vlan-id outer tpid.vlan-id;
```

Copyright © 2014, Juniper Networks, Inc.

```
vlan-tags outer tpid.vlan-id inner-list [vlan-id vlan-id–vlan-id]
vpi vpi-identifier;
family family {
  accounting {
    destination-class-usage;
    source-class-usage {
      direction;
    }
  }
  bundle interface-name;
  filter {
    group filter-group-number;
    input filter-name;
    input-list {
      [ filter-names ];
    }
    output filter-name;
    output-list {
      [ filter-names ];
    }
  }
  ipsec-sa sa-name;
  keep-address-and-control;
  mtu bytes;
  multicast-only;
  no-redirects;
  policer {
    arp policer-template-name;
    input policer-template-name;
    output policer-template-name;
  }
  primary;
  proxy inet-address address;
  receive-options-packets;
  receive-ttl-exceeded;
  remote (inet-address address | mac-address address);
  rpf-check <fail-filter filter-name> {
    <mode loose>;
  }
  sampling {
    direction;
  }
  service {
    input {
      service-set service-set-name <service-filter filter-name>;
      post-service-filter filter-name;
    }
    output {
      service-set service-set-name <service-filter filter-name>;
    }
  }
  (translate-discard-eligible | no-translate-discard-eligible);
  (translate-fecn-and-becn | no-translate-fecn-and-becn);
  unnumbered-address interface-name destination address destination-profile
    profile-name;
  address address {
```


Copyright © 2014, Juniper Networks, Inc.

```
                arp ip-address (mac | multicast-mac) mac-address <publish>;
                broadcast address;
                destination address;
                destination-profile name;
                eui-64;
                multipoint-destination address (dlci dlci-identifier | vci vci-identifier);
                multipoint-destination address {
                  epd-threshold cells plp1 cells;
                  inverse-arp;
                  oam-liveness {
                    up-count cells;
                    down-count cells;
                  }
                  oam-period (seconds | disable);
                  shaping {
                    (cbr rate | rtvbr peak rate sustained rate burst length | vbr peak rate sustained
                      rate burst length);
                    queue-length number;
                  }
                  vci vpi-identifier.vci-identifier;
                }
                preferred;
                primary;
                (vrrp-group | vrrp-inet6-group) group-number {
                  (accept-data | no-accept-data);
                  advertise–interval seconds;
                  authentication-type authentication;
                  authentication-key key;
                  fast-interval milliseconds;
                  (preempt | no-preempt) {
                    hold-time seconds;
                  }
                  priority-number number;
                  track {
                    priority-cost seconds;
                    priority-hold-time interface-name {
                      interface priority;
                      bandwidth-threshold bits-per-second {
                        priority;
                      }
                    }
                    route ip-address/mask routing-instance instance-name priority-cost cost;
                  }
                }
                virtual-address [ addresses ];
              }
            }
          }
        }
      }
```

Related Documentation

- *Junos OS Hierarchy and RFC Reference*
- *Ethernet Interfaces*
- *Junos OS Network Interfaces Library for Routing Devices*

Copyright © 2014, Juniper Networks, Inc.

 Copyright © 2014, Juniper Networks, Inc.

CHAPTER 4

Statement Summary

- family on page 32
- fast-aps-switch on page 36
- passive-monitor-mode on page 37
- receive-options-packets on page 38
- receive-ttl-exceeded on page 38

Copyright © 2014, Juniper Networks, Inc.

family

Syntax

```
family family {
  accounting {
    destination-class-usage;
    source-class-usage {
      (input | output | input output);
    }
  }
  access-concentrator name;
  address address {
    ... the address subhierarchy appears after the main [edit interfaces interface-name unit
      logical-unit-number family family-name] hierarchy ...
  }
  bundle interface-name;
  core-facing;
  demux-destination {
    destination-prefix;
  }
  demux-source {
    source-prefix;
  }
  direct-connect;
  duplicate-protection;
  dynamic-profile profile-name;
  filter {
    group filter-group-number;
    input filter-name;
    input-list [ filter-names ];
    output filter-name;
    output-list [ filter-names ];
  }
  interface-mode (access | trunk);
  ipsec-sa sa-name;
  keep-address-and-control;
  mac-validate (loose | strict);
  max-sessions number;
  max-sessions-vsa-ignore;
  mtu bytes;
  multicast-only;
  negotiate-address;
  no-redirects;
  policer {
    arp policer-template-name;
    input policer-template-name;
    output policer-template-name;
  }
  primary;
  protocols [inet iso mpls];
  proxy inet-address address;
  receive-options-packets;
  receive-ttl-exceeded;
  remote (inet-address address | mac-address address);
  rpf-check {
```


Copyright © 2014, Juniper Networks, Inc.

```
    fail-filter filter-name
    mode loose;
}
sampling {
    input;
    output;
}
service {
    input {
        post-service-filter filter-name;
        service-set service-set-name <service-filter filter-name>;
    }
    output {
        service-set service-set-name <service-filter filter-name>;
    }
}
service-name-table table-name
short-cycle-protection <lockout-time-min minimum-seconds lockout-time-max
    maximum-seconds>;
(translate-discard-eligible | no-translate-discard-eligible);
(translate-fecn-and-becn | no-translate-fecn-and-becn);
translate-plp-control-word-de;
unnumbered-address interface-name destination address destination-profile profile-name;
vlan-id number;
vlan-id-list [number number-number];
address address {
    arp ip-address (mac | multicast-mac) mac-address <publish>;
    broadcast address;
    destination address;
    destination-profile name;
    eui-64;
    master-only;
    multipoint-destination address dlci dlci-identifier;
    multipoint-destination address {
        epd-threshold cells;
        inverse-arp;
        oam-liveness {
            up-count cells;
            down-count cells;
        }
        oam-period (disable | seconds);
        shaping {
            (cbr rate | rtvbr burst length peak rate sustained rate | vbr burst length peak rate
                sustained rate);
            queue-length number;
        }
        vci vpi-identifier.vci-identifier;
    }
    preferred;
    primary;
    vrrp-groupgroup-id {
        (accept-data | no-accept-data);
        advertise-interval seconds;
        authentication-key key;
        authentication-type authentication;
        fast-interval milliseconds;
```

```
        (preempt | no-preempt) {
          hold-time seconds;
        }
        priority number;
        track {
          interface interface-name {
            bandwidth-threshold bits-per-second priority-cost priority;
            priority-cost priority;
          }
          priority-hold-time seconds;
          route prefix routing-instance instance-name priority-cost priority;
          }
        }
        virtual-address [ addresses ];
        }
      virtual-link-local-addressipv6-address;
    }
}
```

Hierarchy Level [edit interfaces *interface-name* unit *logical-unit-number*],
[edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

Release Information Statement introduced before Junos OS Release 7.4.
Option **max-sessions-vsa-ignore** introduced in Junos OS Release 11.4.

Description Configure protocol family information for the logical interface.

NOTE: Not all subordinate stanzas are available to every protocol family.

Copyright © 2014, Juniper Networks, Inc.

Options *family*—Protocol family:

- **any**—Protocol-independent family used for Layer 2 packet filtering

NOTE: This option is not supported on T4000 Type 5 FPCs.

- **bridge**—(M Series and T Series routers only) Configure only when the physical interface is configured with **ethernet-bridge** type encapsulation or when the logical interface is configured with **vlan-bridge** type encapsulation
- **ethernet-switching**—(M Series and T Series routers only) Configure only when the physical interface is configured with **ethernet-bridge** type encapsulation or when the logical interface is configured with **vlan-bridge** type encapsulation
- **ccc**—Circuit cross-connect protocol suite
- **inet**—Internet Protocol version 4 suite
- **inet6**—Internet Protocol version 6 suite
- **iso**—International Organization for Standardization Open Systems Interconnection (ISO OSI) protocol suite
- **mlfr-end-to-end**—Multilink Frame Relay FRF.15
- **mlfr-uni-nni**—Multilink Frame Relay FRF.16
- **multilink-ppp**—Multilink Point-to-Point Protocol
- **mpls**—Multiprotocol Label Switching (MPLS)
- **pppoe**—Point-to-Point Protocol over Ethernet
- **tcc**—Translational cross-connect protocol suite
- **tnp**—Trivial Network Protocol
- **vpls**—(M Series and T Series routers only) Virtual private LAN service

The remaining statements are explained separately.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Documentation

- *Configuring the Protocol Family*
- *Junos OS Services Interfaces Library for Routing Devices*

Copyright © 2014, Juniper Networks, Inc.

fast-aps-switch

Syntax fast-aps-switch;

Hierarchy Level [edit interfaces *interface-name* sonet-options aps]

Release Information Statement introduced in Junos OS Release 12.1.

Description (M320 routers with Channelized OC3/STM1 Circuit Emulation PIC with SFP only and EX Series switches) Reduce the Automatic Protection Switching (APS) switchover time in Layer 2 circuits.

NOTE:

- Configuring this statement reduces the APS switchover time only when the Layer 2 circuit encapsulation type for the interface receiving traffic from a Layer 2 circuit neighbor is SAToP.
- When the **fast-aps-switch** statement is configured in revertive APS mode, you must configure an appropriate value for revert time to achieve reduction in APS switchover time.
- To prevent the logical interfaces in the data path from being shut down, configure appropriate hold-time values on all the interfaces in the data path that support TDM.
- The **fast-aps-switch** statement cannot be configured when the APS **annex-b** option is configured.
- The interfaces that have the **fast-aps-switch** statement configured cannot be used in virtual private LAN service (VPLS) environments.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Documentation

- *Reducing APS Switchover Time in Layer 2 Circuits*

Copyright © 2014, Juniper Networks, Inc.

passive-monitor-mode

Syntax passive-monitor-mode;

Hierarchy Level [edit interfaces *interface-name*],
[edit interfaces *interface-name* unit *logical-unit-number*],
[edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number*]

Release Information Statement introduced before Junos OS Release 7.4.

Description Monitor packet flows from another router. If you include this statement in the configuration, the interface does not send keepalives or alarms, and does not participate actively on the network.

This statement is supported on ATM, Ethernet, and SONET/SDH interfaces. For more information, see *ATM Interfaces Feature Guide for Routing Devices*.

For ATM and Ethernet interfaces, you can include this statement on the physical interface only.

For SONET/SDH interfaces, you can include this statement on the logical interface only.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Documentation

- *Enabling Passive Monitoring on ATM Interfaces*
- Passive Monitoring on Ethernet Interfaces Overview on page 3
- *Enabling Passive Monitoring on SONET/SDH Interfaces*
- *multiservice-options*
- *Junos OS Services Interfaces Library for Routing Devices*

Copyright © 2014, Juniper Networks, Inc.

receive-options-packets

Syntax receive-options-packets;

Hierarchy Level [edit interfaces *interface-name* unit *logical-unit-number* family inet],
[edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number* family inet]

Release Information Statement introduced before Junos OS Release 7.4.

Description For a Monitoring Services PIC and an ATM or SONET/SDH PIC installed in an M160, M40e, or T Series router, guarantee conformity with cflowd records structure. This statement is required when you enable passive monitoring.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Documentation
- *Enabling Passive Monitoring on ATM Interfaces*
- *Enabling Passive Monitoring on SONET/SDH Interfaces*

receive-ttl-exceeded

Syntax receive-ttl-exceeded;

Hierarchy Level [edit interfaces *interface-name* unit *logical-unit-number* family inet],
[edit logical-systems *logical-system-name* interfaces *interface-name* unit *logical-unit-number* family inet]

Release Information Statement introduced before Junos OS Release 7.4.

Description For Monitoring Services PIC and an ATM or SONET/SDH PIC installed in an M160, M40e, or T Series router, guarantee conformity with cflowd records structure. This statement is required when you enable passive monitoring.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Documentation
- *Enabling Passive Monitoring on ATM Interfaces*
- *Enabling Passive Monitoring on SONET/SDH Interfaces*

Copyright © 2014, Juniper Networks, Inc.

PART 3

Administration

- Monitoring Commands on page 41

Copyright © 2014, Juniper Networks, Inc.

Copyright © 2014, Juniper Networks, Inc.

CHAPTER 5

Monitoring Commands

- show interfaces (Adaptive Services)
- show interfaces (Fast Ethernet)
- show interfaces (Gigabit Ethernet)

Copyright © 2014, Juniper Networks, Inc.

show interfaces (Adaptive Services)

Syntax
show interfaces *interface-type*
<brief | detail | extensive | terse>
<descriptions>
<media>
<snmp-index *snmp-index*>
<statistics>

Release Information
Command introduced before Junos OS Release 7.4.

Description
Display status information about the specified adaptive services interface.

Options
interface-type—On M Series and T Series routers, the interface type is **sp-*** ***fpc/pic/port***. On J Series routers, the interface type is **sp-*pim*/0/*port***.

brief | detail | extensive | terse—(Optional) Display the specified level of output.

descriptions—(Optional) Display interface description strings.

media—(Optional) Display media-specific information about network interfaces.

snmp-index *snmp-index*—(Optional) Display information for the specified SNMP index of the interface.

statistics—(Optional) Display static interface statistics.

Required Privilege Level
view

List of Sample Output
show interfaces (Adaptive Services) on page 47
show interfaces brief (Adaptive Services) on page 47
show interfaces detail (Adaptive Services) on page 47
show interfaces extensive (Adaptive Services) on page 48

Output Fields
Table 3 on page 42 lists the output fields for the **show interfaces** (adaptive services and redundant adaptive services) command. Output fields are listed in the approximate order in which they appear.

Table 3: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields

Field Name	Field Description	Level of Output
Physical Interface		
Physical interface	Name of the physical interface.	All levels
Enabled	State of the interface. Possible values are described in the “Enabled Field” section under *Common Output Fields Description*.	All levels
Interface index	Physical interface's index number, which reflects its initialization sequence.	**detail extensive** none
SNMP ifIndex	SNMP index number for the physical interface.	**detail extensive** none

Copyright © 2014, Juniper Networks, Inc.

Table 3: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields *(continued)*

Field Name	Field Description	Level of Output
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**
Type	Encapsulation being used on the interface.	All levels
Link-level type	Encapsulation being used on the physical interface.	All levels
MTU	MTU size on the physical interface.	All levels
Clocking	Reference clock source: can be **Internal** or **External**.	All levels
Speed	Speed at which the interface is running.	All levels
Device flags	Information about the physical device. Possible values are described in the "Device Flags" section under *Common Output Fields Description*.	All levels
Interface flags	Information about the interface. Possible values are described in the "Interface Flags" section under *Common Output Fields Description*.	All levels
Link type	Physical interface link type: **Full-Duplex** or **Half-Duplex**.	**detail extensive** none
Link flags	Information about the link. Possible values are described in the "Link Flags" section under *Common Output Fields Description*.	**detail extensive** none
Physical info	Information about the physical interface.	**detail extensive**
Hold-times	Current interface hold-time up and hold-time down, in milliseconds.	**detail extensive**
Current address	Configured MAC address.	**detail extensive** none
Hardware address	MAC address of the hardware.	**detail extensive** none
Alternate link address	Backup address of the link.	**detail extensive** none
Last flapped	Date, time, and how long ago the interface went from down to up. The format is **Last flapped:** ***year-month-day hour:minute:second timezone*** **(*hour:minute:second* ago)**. For example, **Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago)**.	**detail extensive** none
Input Rate	Input rate in bits per second (bps) and packets per second (pps).	None specified
Output Rate	Output rate in bps and pps.	None specified
Statistics last cleared	Time when the statistics for the interface were last set to zero.	**detail extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 3: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields *(continued)*

Field Name	Field Description	Level of Output
Traffic statistics	Number and rate of bytes and packets received and transmitted on the physical interface. • **Input bytes**—Number of bytes received on the interface. • **Output bytes**—Number of bytes transmitted on the interface. • **Input packets**—Number of packets received on the interface. • **Output packets**—Number of packets transmitted on the interface.	**detail extensive**
Input errors	Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious: • **Errors**—Sum of the incoming frame aborts and FCS errors. • **Drops**—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism. • **Framing errors**—Number of packets received with an invalid frame checksum (FCS). • **Runts**—Frames received smaller than the runt threshold. • **Giants**—Frames received larger than the giant threshold. • **Policed discards**—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle. • **Resource errors**—Sum of transmit drops.	**extensive**
Output errors	Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious: • **Carrier transitions**—Number of times the interface has gone from **down** to **up**. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC is malfunctioning. • **Errors**—Sum of the outgoing frame aborts and FCS errors. • **Drops**—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism. • **MTU errors**—Number of packets larger than the MTU threshold. • **Resource errors**—Sum of transmit drops.	**extensive**
Logical Interface		
Logical interface	Name of the logical interface.	All levels
Index	Logical interface index number, which reflects its initialization sequence.	**detail extensive** none
SNMP ifIndex	SNMP interface index number.	**detail extensive** none
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 3: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields *(continued)*

Field Name	Field Description	Level of Output
Flags	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under *Common Output Fields Description*.	All levels
Encapsulation	Encapsulation on the logical interface.	All levels
Input packets	Number of packets received on the logical interface.	None specified
Output packets	Number of packets transmitted on the logical interface.	None specified
Traffic statistics	Number and rate of bytes and packets received and transmitted on the logical interface. • **Input bytes**—Number of bytes received on the interface. • **Output bytes**—Number of bytes transmitted on the interface. • **Input packets**—Number of packets received on the interface. • **Output packets**—Number of packets transmitted on the interface.	**detail extensive**
Local statistics	Statistics for traffic received from and transmitted to the Routing Engine. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes awhile (generally, less than 1 second) for this counter to stabilize.	**detail extensive**
Transit statistics	Statistics for traffic transiting the router. When a burst of traffic is received, the value in the output packet rate field might briefly exceed the peak cell rate. It takes generally less than 1 second for the counter to stabilize.	**detail extensive**
protocol-family	Protocol family configured on the logical interface. If the protocol is **inet**, the IP address of the interface is also displayed.	**brief**
Protocol	Protocol family configured on the logical interface, such as **iso**, **inet6**, **mpls**.	**detail extensive** none
MTU	MTU size on the logical interface.	**detail extensive** none
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**
Route table	Routing table in which the logical interface address is located. For example, **0** refers to the routing table inet.0.	**detail extensive**
Flags	Information about the protocol family flags. Possible values are described in the "Family Flags" section under *Common Output Fields Description*.	**detail extensive** none
Addresses, Flags	Information about the address flags. Possible values are described in the "Addresses Flags" section under *Common Output Fields Description*.	**detail extensive** none
Destination	IP address of the remote side of the connection.	**detail extensive** none
Local	IP address of the logical interface.	**detail extensive** none

Copyright © 2014, Juniper Networks, Inc.

Table 3: Adaptive Services and Redundant Adaptive Services show interfaces Output Fields *(continued)*

Field Name	Field Description	Level of Output
Broadcast	Broadcast address.	**detail extensive** none
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**

Copyright © 2014, Juniper Networks, Inc.

Sample Output

show interfaces (Adaptive Services)

```
user@host> show interfaces sp-1/2/0
Physical interface: sp-1/2/0, Enabled, Physical link is Up
  Interface index: 147, SNMP ifIndex: 72
  Type: Adaptive-Services, Link-level type: Adaptive-Services, MTU: 9192,
  Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Last flapped   : 2006-03-06 11:37:18 PST (00:57:29 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)

  Logical interface sp-1/2/0.16383 (Index 68) (SNMP ifIndex 73)
    Flags: Point-To-Point SNMP-Traps Encapsulation: Adaptive-Services
    Input packets : 3057
    Output packets: 3044
    Protocol inet, MTU: 9192
      Flags: Receive-options, Receive-TTL-Exceeded
      Addresses, Flags: Is-Preferred Is-Primary
        Destination: 10.0.0.34, Local: 10.0.0.1
```

show interfaces brief (Adaptive Services)

```
user@host> show interfaces sp-1/2/0 brief
Physical interface: sp-1/2/0, Enabled, Physical link is Up
  Type: Adaptive-Services, Link-level type: Adaptive-Services, MTU: 9192,
  Clocking: Unspecified, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000

  Logical interface sp-1/2/0.16383
    Flags: Point-To-Point SNMP-Traps Encapsulation: Adaptive-Services
    inet  10.0.0.1         --> 10.0.0.34
```

show interfaces detail (Adaptive Services)

```
user@host> show interfaces sp-1/2/0 detail
Physical interface: sp-1/2/0, Enabled, Physical link is Up
  Interface index: 147, SNMP ifIndex: 72, Generation: 30
  Type: Adaptive-Services, Link-level type: Adaptive-Services, MTU: 9192,
  Clocking: Unspecified, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : 2006-03-06 11:37:18 PST (00:57:56 ago)
  Statistics last cleared: Never
  Traffic statistics:
   Input  bytes  :              125147                 0 bps
   Output bytes  :             1483113                 0 bps
   Input  packets:                3061                 0 pps
   Output packets:                3048                 0 pps
```

Copyright © 2014, Juniper Networks, Inc.

```
  Logical interface sp-1/2/0.16383 (Index 68) (SNMP ifIndex 73) (Generation 7)
    Flags: Point-To-Point SNMP-Traps Encapsulation: Adaptive-Services
    Traffic statistics:
     Input  bytes  :               125147
     Output bytes  :              1483113
     Input  packets:                 3061
     Output packets:                 3048
    Local statistics:
     Input  bytes  :               125147
     Output bytes  :              1483113
     Input  packets:                 3061
     Output packets:                 3048
    Transit statistics:
     Input  bytes  :                    0                    0 bps
     Output bytes  :                    0                    0 bps
     Input  packets:                    0                    0 pps
     Output packets:                    0                    0 pps
    Protocol inet, MTU: 9192, Generation: 20, Route table: 1
      Flags: Receive-options, Receive-TTL-Exceeded
      Addresses, Flags: Is-Preferred Is-Primary
        Destination: 10.0.0.34, Local: 10.0.0.1, Broadcast: Unspecified,
        Generation: 22
```

show interfaces extensive (Adaptive Services)

```
user@host> show interfaces sp-1/2/0 extensive
Physical interface: sp-1/2/0, Enabled, Physical link is Up
  Interface index: 147, SNMP ifIndex: 72, Generation: 30
  Type: Adaptive-Services, Link-level type: Adaptive-Services, MTU: 9192,
  Clocking: Unspecified, Speed: 800mbps
  Device flags   : Present Running
  Interface flags: Point-To-Point SNMP-Traps Internal: 0x4000
  Link type      : Full-Duplex
  Link flags     : None
  Physical info  : Unspecified
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: Unspecified, Hardware address: Unspecified
  Alternate link address: Unspecified
  Last flapped   : 2006-03-06 11:37:18 PST (00:58:40 ago)
  Statistics last cleared: Never
  Traffic statistics:
   Input  bytes  :               125547                    0 bps
   Output bytes  :              1483353                    0 bps
   Input  packets:                 3065                    0 pps
   Output packets:                 3052                    0 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Giants: 0,
    Policed discards: 0, Resource errors: 0
  Output errors:
    Carrier transitions: 2, Errors: 0, Drops: 0, MTU errors: 0,
    Resource errors: 0

  Logical interface sp-1/2/0.16383 (Index 68) (SNMP ifIndex 73) (Generation 7)
    Flags: Point-To-Point SNMP-Traps Encapsulation: Adaptive-Services
    Traffic statistics:
     Input  bytes  :               125547
     Output bytes  :              1483353
     Input  packets:                 3065
     Output packets:                 3052
    Local statistics:
```


Copyright © 2014, Juniper Networks, Inc.

```
 Input  bytes  :               125547
 Output bytes  :              1483353
 Input  packets:                 3065
 Output packets:                 3052
Transit statistics:
 Input  bytes  :                    0                    0 bps
 Output bytes  :                    0                    0 bps
 Input  packets:                    0                    0 pps
 Output packets:                    0                    0 pps
Protocol inet, MTU: 9192, Generation: 20, Route table: 1
  Flags: Receive-options, Receive-TTL-Exceeded
  Addresses, Flags: Is-Preferred Is-Primary
    Destination: 10.0.0.34, Local: 10.0.0.1, Broadcast: Unspecified,
    Generation: 22
```

show interfaces (Fast Ethernet)

Syntax

show interfaces *interface-type*
<brief | detail | extensive | terse>
<descriptions>
<media>
<snmp-index *snmp-index*>
<statistics>

Release Information

Command introduced before Junos OS Release 7.4.

Description

Display status information about the specified Fast Ethernet interface.

Options

interface-type—On M Series and T Series routers, the interface type is **fe-*fpc/pic/port***. On the J Series routers, the interface type is **fe-*pim*/0/*port***.

brief | detail | extensive | terse—(Optional) Display the specified level of output.

descriptions—(Optional) Display interface description strings.

media—(Optional) Display media-specific information about network interfaces.

snmp-index *snmp-index*—(Optional) Display information for the specified SNMP index of the interface.

statistics—(Optional) Display static interface statistics.

Required Privilege Level

view

List of Sample Output

show interfaces (Fast Ethernet) on page 63
show interfaces brief (Fast Ethernet) on page 64
show interfaces detail (Fast Ethernet) on page 64
show interfaces extensive (Fast Ethernet) on page 64

Output Fields

Table 4 on page 50 lists the output fields for the **show interfaces Fast Ethernet** command. Output fields are listed in the approximate order in which they appear.

Table 4: show interfaces Fast Ethernet Output Fields

Field Name	Field Description	Level of Output
Physical Interface		
Physical interface	Name of the physical interface.	All levels
Enabled	State of the interface. Possible values are described in the "Enabled Field" section under *Common Output Fields Description*.	All levels
Interface index	Index number of the physical interface, which reflects its initialization sequence.	**detail extensive** none
SNMP ifIndex	SNMP index number for the physical interface.	**detail extensive** none

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**
Link-level type	Encapsulation being used on the physical interface.	All levels
MTU	Maximum transmission unit size on the physical interface.	All levels
Link-mode	Type of link connection configured for the physical interface: **Full-duplex** or **Half-duplex**	**extensive**
Speed	Speed at which the interface is running.	All levels
Loopback	Loopback status: **Enabled** or **Disabled**. If loopback is enabled, type of loopback: **Local** or **Remote**.	All levels
Source filtering	Source filtering status: **Enabled** or **Disabled**.	All levels
LAN-PHY mode	10-Gigabit Ethernet interface operating in Local Area Network Physical Layer Device (LAN PHY) mode. LAN PHY allows 10-Gigabit Ethernet wide area links to use existing Ethernet applications.	All levels
WAN-PHY mode	10-Gigabit Ethernet interface operating in Wide Area Network Physical Layer Device (WAN PHY) mode. WAN PHY allows 10-Gigabit Ethernet wide area links to use fiber-optic cables and other devices intended for SONET/SDH.	All levels
Unidirectional	Unidirectional link mode status for 10-Gigabit Ethernet interface: **Enabled** or **Disabled** for parent interface; **Rx-only** or **Tx-only** for child interfaces.	All levels
Flow control	Flow control status: **Enabled** or **Disabled**.	All levels
Auto-negotiation	(Gigabit Ethernet interfaces) Autonegotiation status: **Enabled** or **Disabled**.	All levels
Remote-fault	(Gigabit Ethernet interfaces) Remote fault status: • **Online**—Autonegotiation is manually configured as online. • **Offline**—Autonegotiation is manually configured as offline.	All levels
Device flags	Information about the physical device. Possible values are described in the "Device Flags" section under *Common Output Fields Description*.	All levels
Interface flags	Information about the interface. Possible values are described in the "Interface Flags" section under *Common Output Fields Description*.	All levels
Link flags	Information about the link. Possible values are described in the "Links Flags" section under *Common Output Fields Description*.	All levels
Wavelength	(10-Gigabit Ethernet dense wavelength-division multiplexing [DWDM] interfaces) Displays the configured wavelength, in nanometers (nm).	All levels

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Frequency	(10-Gigabit Ethernet DWDM interfaces only) Displays the frequency associated with the configured wavelength, in terahertz (THz).	All levels
CoS queues	Number of CoS queues configured.	**detail extensive** none
Schedulers	(GigabitEthernet intelligent queuing 2 (IQ2) interfaces only) Number of CoS schedulers configured.	**extensive**
Hold-times	Current interface hold-time up and hold-time down, in milliseconds.	**detail extensive**
Current address	Configured MAC address.	**detail extensive** none
Hardware address	Hardware MAC address.	**detail extensive** none
Last flapped	Date, time, and how long ago the interface went from down to up. The format is **Last flapped:** ***year-month-day hour:minute:second:timezone*** **(*hour:minute:second* ago)**. For example, **Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago).**	**detail extensive** none
Input Rate	Input rate in bits per second (bps) and packets per second (pps).	None specified
Output Rate	Output rate in bps and pps.	None specified
Statistics last cleared	Time when the statistics for the interface were last set to zero.	**detail extensive**
Traffic statistics	Number and rate of bytes and packets received and transmitted on the physical interface. • **Input bytes**—Number of bytes received on the interface • **Output bytes**—Number of bytes transmitted on the interface. • **Input packets**—Number of packets received on the interface. • **Output packets**—Number of packets transmitted on the interface. Gigabit Ethernet and 10-Gigabit Ethernet IQ PICs count the overhead and CRC bytes. For Gigabit Ethernet IQ PICs, the input byte counts vary by interface type. For more information, see Table 31 under the *show interfaces (10-Gigabit Ethernet)* command.	**detail extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Input errors	Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious: • **Errors**—Sum of the incoming frame aborts and FCS errors. • **Drops**—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism. • **Framing errors**—Number of packets received with an invalid frame checksum (FCS). • **Runts**—Number of frames received that are smaller than the runt threshold. • **Policed discards**—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle. • **L3 incompletes**—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded. L3 incomplete errors can be ignored by configuring the **ignore-l3-incompletes** statement. • **L2 channel errors**—Number of times the software did not find a valid logical interface for an incoming frame. • **L2 mismatch timeouts**—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable. • **FIFO errors**—Number of FIFO errors in the receive direction that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning. • **Resource errors**—Sum of transmit drops.	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Output errors	Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious: • **Carrier transitions**—Number of times the interface has gone from **down** to **up**. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning. • **Errors**—Sum of the outgoing frame aborts and FCS errors. • **Drops**—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism. • **Collisions**—Number of Ethernet collisions. The Gigabit Ethernet PIC supports only full-duplex operation, so for Gigabit Ethernet PICs, this number should always remain 0. If it is nonzero, there is a software bug. • **Aged packets**—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware. • **FIFO errors**—Number of FIFO errors in the send direction as reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning. • **HS link CRC errors**—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces. • **MTU errors**—Number of packets whose size exceeded the MTU of the interface. • **Resource errors**—Sum of transmit drops.	**extensive**
Egress queues	Total number of egress queues supported on the specified interface.	**detail extensive**
Queue counters (Egress)	CoS queue number and its associated user-configured forwarding class name. • **Queued packets**—Number of queued packets. • **Transmitted packets**—Number of transmitted packets. • **Dropped packets**—Number of packets dropped by the ASIC's RED mechanism.	**detail extensive**
Ingress queues	Total number of ingress queues supported on the specified interface. Displayed on IQ2 interfaces.	**extensive**
Queue counters (Ingress)	CoS queue number and its associated user-configured forwarding class name. Displayed on IQ2 interfaces. • **Queued packets**—Number of queued packets. • **Transmitted packets**—Number of transmitted packets. • **Dropped packets**—Number of packets dropped by the ASIC's RED mechanism.	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Active alarms and Active defects	Ethernet-specific defects that can prevent the interface from passing packets. When a defect persists for a certain amount of time, it is promoted to an alarm. Based on the routing device configuration, an alarm can ring the red or yellow alarm bell on the routing device, or turn on the red or yellow alarm LED on the craft interface. These fields can contain the value **None** or **Link**. • **None**—There are no active defects or alarms. • **Link**—Interface has lost its link state, which usually means that the cable is unplugged, the far-end system has been turned off, or the PIC is malfunctioning.	**detail extensive** none
OTN FEC statistics	The forward error correction (FEC) counters provide the following statistics:. • **Corrected Errors**—The count of corrected errors in the last second. • **Corrected Error Ratio**—The corrected error ratio in the last 25 seconds. For example, 1e-7 is 1 error per 10 million bits.	
PCS statistics	(10-Gigabit Ethernet interfaces) Displays Physical Coding Sublayer (PCS) fault conditions from the WAN PHY or the LAN PHY device. • **Bit errors**—High bit error rate. Indicates the number of bit errors when the PCS receiver is operating in normal mode. • **Errored blocks**—Loss of block lock. The number of errored blocks when PCS receiver is operating in normal mode.	**detail extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
MAC statistics	**Receive** and **Transmit** statistics reported by the PIC's MAC subsystem, including the following: • **Total octets** and **total packets**—Total number of octets and packets. For Gigabit Ethernet IQ PICs, the received octets count varies by interface type. For more information, see Table 31 under the *show interfaces (10-Gigabit Ethernet)* command. • **Unicast packets, Broadcast packets,** and **Multicast packets**—Number of unicast, broadcast, and multicast packets. • **CRC/Align errors**—Total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error). • **FIFO error**—Number of FIFO errors that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC or a cable is probably malfunctioning. • **MAC control frames**—Number of MAC control frames. • **MAC pause frames**—Number of MAC control frames with **pause** operational code. • **Oversized frames**—Number of frames that exceed 1518 octets. • **Jabber frames**—Number of frames that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition in which any packet exceeds 20 ms. The allowed range to detect jabber is from 20 ms to 150 ms. • **Fragment frames**—Total number of packets that were less than 64 octets in length (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. Fragment frames normally increment because both runts (which are normal occurrences caused by collisions) and noise hits are counted. • **VLAN tagged frames**—Number of frames that are VLAN tagged. The system uses the TPID of 0x8100 in the frame to determine whether a frame is tagged or not. • **Code violations**—Number of times an event caused the PHY to indicate “Data reception error” or “invalid data symbol error.”	**extensive**
OTN Received Overhead Bytes	APS/PCC0: 0x02, APS/PCC1: 0x11, APS/PCC2: 0x47, APS/PCC3: 0x58 Payload Type: 0x08	**extensive**
OTN Transmitted Overhead Bytes	APS/PCC0: 0x00, APS/PCC1: 0x00, APS/PCC2: 0x00, APS/PCC3: 0x00 Payload Type: 0x08	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Filter statistics	**Receive** and **Transmit** statistics reported by the PIC's MAC address filter subsystem. The filtering is done by the content-addressable memory (CAM) on the PIC. The filter examines a packet's source and destination MAC addresses to determine whether the packet should enter the system or be rejected. • **Input packet count**—Number of packets received from the MAC hardware that the filter processed. • **Input packet rejects**—Number of packets that the filter rejected because of either the source MAC address or the destination MAC address. • **Input DA rejects**—Number of packets that the filter rejected because the destination MAC address of the packet is not on the accept list. It is normal for this value to increment. When it increments very quickly and no traffic is entering the routing device from the far-end system, either there is a bad ARP entry on the far-end system, or multicast routing is not on and the far-end system is sending many multicast packets to the local routing device (which the routing device is rejecting). • **Input SA rejects**—Number of packets that the filter rejected because the source MAC address of the packet is not on the accept list. The value in this field should increment only if source MAC address filtering has been enabled. If filtering is enabled, if the value increments quickly, and if the system is not receiving traffic that it should from the far-end system, it means that the user-configured source MAC addresses for this interface are incorrect. • **Output packet count**—Number of packets that the filter has given to the MAC hardware. • **Output packet pad count**—Number of packets the filter padded to the minimum Ethernet size (60 bytes) before giving the packet to the MAC hardware. Usually, padding is done only on small ARP packets, but some very small IP packets can also require padding. If this value increments rapidly, either the system is trying to find an ARP entry for a far-end system that does not exist or it is misconfigured. • **Output packet error count**—Number of packets with an indicated error that the filter was given to transmit. These packets are usually aged packets or are the result of a bandwidth problem on the FPC hardware. On a normal system, the value of this field should not increment. • **CAM destination filters, CAM source filters**—Number of entries in the CAM dedicated to destination and source MAC address filters. There can only be up to 64 source entries. If source filtering is disabled, which is the default, the values for these fields should be 0.	**extensive**
PMA PHY	(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET error information: • **Seconds**—Number of seconds the defect has been active. • **Count**—Number of times that the defect has gone from inactive to active. • **State**—State of the error. Any state other than **OK** indicates a problem. Subfields are: • **PHY Lock**—Phase-locked loop • **PHY Light**—Loss of optical signal	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
WIS section	(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET error information: • **Seconds**—Number of seconds the defect has been active. • **Count**—Number of times that the defect has gone from inactive to active. • **State**—State of the error. Any state other than **OK** indicates a problem. Subfields are: • **BIP-B1**—Bit interleaved parity for SONET section overhead • **SEF**—Severely errored framing • **LOL**—Loss of light • **LOF**—Loss of frame • **ES-S**—Errored seconds (section) • S**ES-S**—Severely errored seconds (section) • **SEFS-S**—Severely errored framing seconds (section)	**extensive**
WIS line	(10-Gigabit Ethernet interfaces, WAN PHY mode) Active alarms and defects, plus counts of specific SONET errors with detailed information. • **Seconds**—Number of seconds the defect has been active. • **Count**—Number of times that the defect has gone from inactive to active. • **State**—State of the error. State other than **OK** indicates a problem. Subfields are: • **BIP-B2**—Bit interleaved parity for SONET line overhead • **REI-L**—Remote error indication (near-end line) • **RDI-L**—Remote defect indication (near-end line) • **AIS-L**—Alarm indication signal (near-end line) • **BERR-SF**—Bit error rate fault (signal failure) • **BERR-SD**—Bit error rate defect (signal degradation) • **ES-L**—Errored seconds (near-end line) • **SES-L**—Severely errored seconds (near-end line) • **UAS-L**—Unavailable seconds (near-end line) • **ES-LFE**—Errored seconds (far-end line) • **SES-LFE**—Severely errored seconds (far-end line) • **UAS-LFE**—Unavailable seconds (far-end line)	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
WIS path	(10-Gigabit Ethernet interfaces, WAN PHY mode) Active alarms and defects, plus counts of specific SONET errors with detailed information. • **Seconds**—Number of seconds the defect has been active. • **Count**—Number of times that the defect has gone from inactive to active. • **State**—State of the error. Any state other than **OK** indicates a problem. Subfields are: • **BIP-B3**—Bit interleaved parity for SONET section overhead • **REI-P**—Remote error indication • **LOP-P**—Loss of pointer (path) • **AIS-P**—Path alarm indication signal • **RDI-P**—Path remote defect indication • **UNEQ-P**—Path unequipped • **PLM-P**—Path payload (signal) label mismatch • **ES-P**—Errored seconds (near-end STS path) • **SES-P**—Severely errored seconds (near-end STS path) • **UAS-P**—Unavailable seconds (near-end STS path) • **SES-PFE**—Severely errored seconds (far-end STS path) • **UAS-PFE**—Unavailable seconds (far-end STS path)	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output

Autonegotiation information	Information about link autonegotiation.
	• **Negotiation status:**
	  • **Incomplete**—Ethernet interface has the speed or link mode configured.
	  • **No autonegotiation**—Remote Ethernet interface has the speed or link mode configured, or does not perform autonegotiation.
	  • **Complete**—Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.
	• **Link partner status**—**OK** when Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.
	• **Link partner:**
	  • **Link mode**—Depending on the capability of the attached Ethernet device, either **Full-duplex** or **Half-duplex**.
	  • **Flow control**—Types of flow control supported by the remote Ethernet device. For Fast Ethernet interfaces, the type is **None**. For Gigabit Ethernet interfaces, types are **Symmetric** (link partner supports **PAUSE** on receive and transmit), **Asymmetric** (link partner supports **PAUSE** on transmit), and **Symmetric/Asymmetric** (link partner supports both **PAUSE** on receive and transmit or only **PAUSE** receive).
	  • **Remote fault**—Remote fault information from the link partner—**Failure** indicates a receive link error. **OK** indicates that the link partner is receiving. **Negotiation error** indicates a negotiation error. **Offline** indicates that the link partner is going offline.
	• **Local resolution**—Information from the link partner:
	  • **Flow control**—Types of flow control supported by the remote Ethernet device. For Gigabit Ethernet interfaces, types are **Symmetric** (link partner supports **PAUSE** on receive and transmit), **Asymmetric** (link partner supports **PAUSE** on transmit), and **Symmetric/Asymmetric** (link partner supports both **PAUSE** on receive and transmit or only **PAUSE** receive).
	  • **Remote fault**—Remote fault information. **Link OK** (no error detected on receive), **Offline** (local interface is offline), and **Link Failure** (link error detected on receive).
		extensive

Received path trace, Transmitted path trace	(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other routing device manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the routing device at the other end of the fiber. The transmitted path trace value is the message that this routing device transmits.	**extensive**
Packet Forwarding Engine configuration	Information about the configuration of the Packet Forwarding Engine: • **Destination slot**—FPC slot number.	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
CoS information	Information about the CoS queue for the physical interface. • **CoS transmit queue**—Queue number and its associated user-configured forwarding class name. • **Bandwidth %**—Percentage of bandwidth allocated to the queue. • **Bandwidth bps**—Bandwidth allocated to the queue (in bps). • **Buffer %**—Percentage of buffer space allocated to the queue. • **Buffer usec**—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time. • **Priority**—Queue priority: **low** or **high**. • **Limit**—Displayed if rate limiting is configured for the queue. Possible values are **none** and **exact**. If **exact** is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If **none** is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.	**extensive**
Logical Interface		
Logical interface	Name of the logical interface.	All levels
Index	Index number of the logical interface, which reflects its initialization sequence.	**detail extensive** none
SNMP ifIndex	SNMP interface index number for the logical interface.	**detail extensive** none
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**
Flags	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under *Common Output Fields Description*.	All levels
VLAN-Tag	Rewrite profile applied to incoming or outgoing frames on the outer (**Out**) VLAN tag or for both the outer and inner (**In**) VLAN tags. • **push**—An outer VLAN tag is pushed in front of the existing VLAN tag. • **pop**—The outer VLAN tag of the incoming frame is removed. • **swap**—The outer VLAN tag of the incoming frame is overwritten with the user specified VLAN tag information. • **push**—An outer VLAN tag is pushed in front of the existing VLAN tag. • **push-push**—Two VLAN tags are pushed in from the incoming frame. • **swap-push**—The outer VLAN tag of the incoming frame is replaced by a user-specified VLAN tag value. A user-specified outer VLAN tag is pushed in front. The outer tag becomes an inner tag in the final frame. • **swap-swap**—Both the inner and the outer VLAN tags of the incoming frame are replaced by the user specified VLAN tag value. • **pop-swap**—The outer VLAN tag of the incoming frame is removed, and the inner VLAN tag of the incoming frame is replaced by the user-specified VLAN tag value. The inner tag becomes the outer tag in the final frame. • **pop-pop**—Both the outer and inner VLAN tags of the incoming frame are removed.	**brief detail extensive** none

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Demux:	IP demultiplexing (demux) value that appears if this interface is used as the demux underlying interface. The output is one of the following: • Source Family Inet • Destination Family Inet	**detail extensive** none
Encapsulation	Encapsulation on the logical interface.	All levels
Protocol	Protocol family. Possible values are described in the "Protocol Field" section under *Common Output Fields Description*.	**detail extensive** none
MTU	Maximum transmission unit size on the logical interface.	**detail extensive** none
Maximum labels	Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.	**detail extensive** none
Traffic statistics	Number and rate of bytes and packets received and transmitted on the specified interface set. • **Input bytes, Output bytes**—Number of bytes received and transmitted on the interface set • **Input packets, Output packets**—Number of packets received and transmitted on the interface set.	**detail extensive**
IPv6 transit statistics	Number of IPv6 transit bytes and packets received and transmitted on the logical interface if IPv6 statistics tracking is enabled.	**extensive**
Local statistics	Number and rate of bytes and packets destined to the routing device.	**extensive**
Transit statistics	Number and rate of bytes and packets transiting the switch. NOTE: For Gigabit Ethernet intelligent queuing 2 (IQ2) interfaces, the logical interface egress statistics might not accurately reflect the traffic on the wire when output shaping is applied. Traffic management output shaping might drop packets after they are tallied by the **Output bytes** and **Output packets** interface counters. However, correct values display for both of these egress statistics when per-unit scheduling is enabled for the Gigabit Ethernet IQ2 physical interface, or when a single logical interface is actively using a shared scheduler.	**extensive**
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**
Route Table	Route table in which the logical interface address is located. For example, **0** refers to the routing table inet.0.	**detail extensive** none
Flags	Information about protocol family flags. Possible values are described in the "Family Flags" section under *Common Output Fields Description*.	**detail extensive**
Donor interface	(Unnumbered Ethernet) Interface from which an unnumbered Ethernet interface borrows an IPv4 address.	**detail extensive** none

Copyright © 2014, Juniper Networks, Inc.

Table 4: show interfaces Fast Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Preferred source address	(Unnumbered Ethernet) Secondary IPv4 address of the donor loopback interface that acts as the preferred source address for the unnumbered Ethernet interface.	**detail extensive** none
Input Filters	Names of any input filters applied to this interface. If you specify a precedence value for any filter in a dynamic profile, filter precedence values appear in parenthesis next to all interfaces.	**detail extensive**
Output Filters	Names of any output filters applied to this interface. If you specify a precedence value for any filter in a dynamic profile, filter precedence values appear in parenthesis next to all interfaces.	**detail extensive**
Mac-Validate Failures	Number of MAC address validation failures for packets and bytes. This field is displayed when MAC address validation is enabled for the logical interface.	**detail extensive** none
Addresses, Flags	Information about the address flags. Possible values are described in the "Addresses Flags" section under *Common Output Fields Description*.	**detail extensive** none
protocol-family	Protocol family configured on the logical interface. If the protocol is **inet**, the IP address of the interface is also displayed.	**brief**
Flags	Information about address flag (possible values are described in the "Addresses Flags" section under *Common Output Fields Description*.	**detail extensive** none
Destination	IP address of the remote side of the connection.	**detail extensive** none
Local	IP address of the logical interface.	**detail extensive** none
Broadcast	Broadcast address of the logical interlace.	**detail extensive** none
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**

Sample Output

show interfaces (Fast Ethernet)

```
user@host> show interfaces fe-0/0/0
Physical interface: fe-0/0/0, Enabled, Physical link is Up
  Interface index: 128, SNMP ifIndex: 22
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues     : 4 supported, 4 maximum usable queues
  Current address: 00:05:85:02:38:00, Hardware address: 00:05:85:02:38:00
  Last flapped   : 2006-01-20 14:50:58 PST (2w4d 00:44 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
  Active alarms  : None
  Active defects : None
  Logical interface fe-0/0/0.0 (Index 66) (SNMP ifIndex 198)
    Flags: SNMP-Traps Encapsulation: ENET2
```

Copyright © 2014, Juniper Networks, Inc.

```
    Protocol inet, MTU: 1500
      Flags: None
      Addresses, Flags: Is-Preferred Is-Primary
        Destination: 10.10.10/24, Local: 10.10.10.1, Broadcast: 10.10.10.255
```

show interfaces brief (Fast Ethernet)

```
user@host> show interfaces fe-0/0/0 brief
Physical interface: fe-0/0/0, Enabled, Physical link is Up
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Logical interface fe-0/0/0.0
    Flags: SNMP-Traps Encapsulation: ENET2
    inet  10.10.10.1/24
```

show interfaces detail (Fast Ethernet)

```
user@host> show interfaces fe-0/0/0 detail
Physical interface: fe-0/0/0, Enabled, Physical link is Up
  Interface index: 128, SNMP ifIndex: 22, Generation: 5391
  Link-level type: Ethernet, MTU: 1514, Speed: 100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues     : 4 supported, 4 maximum usable queues
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:05:85:02:38:00, Hardware address: 00:05:85:02:38:00
  Last flapped   : 2006-01-20 14:50:58 PST (2w4d 00:45 ago)
  Statistics last cleared: Never
  Traffic statistics:
   Input  bytes  :                    0                    0 bps
   Output bytes  :                   42                    0 bps
   Input  packets:                    0                    0 pps
   Output packets:                    1                    0 pps
  Active alarms  : None
  Active defects : None
  Logical interface fe-0/0/0.0 (Index 66) (SNMP ifIndex 198) (Generation 67)
    Flags: SNMP-Traps Encapsulation: ENET2
    Protocol inet, MTU: 1500, Generation: 105, Route table: 0
      Flags: Is-Primary, Mac-Validate-Strict
      Mac-Validate Failures: Packets: 0, Bytes: 0
      Addresses, Flags: Is-Preferred Is-Primary
      Destination: 10.10.10/24, Local: 10.10.10.1, Broadcast: 10.10.10.255,
        Generation: 136
```

show interfaces extensive (Fast Ethernet)

```
user@host> show interfaces fe-0/0/0 extensive
Physical interface: fe-0/0/0, Enabled, Physical link is Up
  Interface index: 128, SNMP ifIndex: 22, Generation: 5391
  Link-level type: Ethernet, MTU: 1514, Link-mode: Full-duplex, Speed:
  100mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues     : 4 supported, 4 maximum usable queues
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:05:85:02:38:00, Hardware address: 00:05:85:02:38:00
  Last flapped   : 2006-01-20 14:50:58 PST (2w4d 00:46 ago)
  Statistics last cleared: Never
```


Copyright © 2014, Juniper Networks, Inc.

```
  Traffic statistics:
   Input  bytes  :                    0                    0 bps
   Output bytes  :                   42                    0 bps
   Input  packets:                    0                    0 pps
   Output packets:                    1                    0 pps
  Input errors:
    Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
    L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
    FIFO errors: 0, Resource errors: 0
  Output errors:
    Carrier transitions: 3, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,

    FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
  Active alarms  : None
  Active defects : None
  MAC statistics:                       Receive         Transmit
    Total octets                              0               64
    Total packets                             0                1
    Unicast packets                           0                0
    Broadcast packets                         0                1
    Multicast packets                         0                0
    CRC/Align errors                          0                0
    FIFO errors                               0                0
    MAC control frames                        0                0
    MAC pause frames                          0                0
    Oversized frames                          0
    Jabber frames                             0
    Fragment frames                           0
    VLAN tagged frames                        0
    Code violations                           0
Filter statistics:
    Input packet count                        0
    Input packet rejects                      0
    Input DA rejects                          0
    Input SA rejects                          0
    Output packet count                               1
    Output packet pad count                           0
    Output packet error count                         0
    CAM destination filters: 1, CAM source filters: 0
  Autonegotiation information:
    Negotiation status: Complete
    Link partner:
        Link partner: Full-duplex, Flow control: None, Remote fault: Ok
    Local resolution:
Packet Forwarding Engine configuration:
    Destination slot: 0
CoS information:
                Bandwidth           Buffer Priority   Limit
                              %          bps   %         usec
    0 best-effort            95    950000000  95            0      low    none
    3 network-control         5     50000000   5            0      low    none
  Logical interface fe-0/0/0.0 (Index 66) (SNMP ifIndex 198) (Generation 67)
    Flags: SNMP-Traps Encapsulation: ENET2
    Protocol inet, MTU: 1500, Generation: 105, Route table: 0
      Flags: None
      Addresses, Flags: Is-Preferred Is-Primary
        Destination: 10.10.10/24, Local: 10.10.10.1, Broadcast: 10.10.10.255,
        Generation: 136
```

Copyright © 2014, Juniper Networks, Inc.

show interfaces (Gigabit Ethernet)

Syntax

show interfaces ge-*fpc/pic/port*
<brief | detail | extensive | terse>
<descriptions>
<media>
<snmp-index *snmp-index*>
<statistics>

Release Information

Command introduced before Junos OS Release 7.4.

Description

(M Series, T Series, and MX Series routers and EX Series switches only) Display status information about the specified Gigabit Ethernet interface.

Options

ge-*fpc/pic/port*—Display standard information about the specified Gigabit Ethernet interface.

brief | detail | extensive | terse—(Optional) Display the specified level of output.

descriptions—(Optional) Display interface description strings.

media—(Optional) Display media-specific information about network interfaces.

snmp-index *snmp-index*—(Optional) Display information for the specified SNMP index of the interface.

statistics—(Optional) Display static interface statistics.

Additional Information

In a logical system, this command displays information only about the logical interfaces and not about the physical interfaces.

Required Privilege Level

view

Related Documentation

- *Verifying and Managing Agent Circuit Identifier-Based Dynamic VLAN Configuration*

List of Sample Output

show interfaces (Gigabit Ethernet) on page 81
show interfaces (Gigabit Ethernet on MX Series Routers) on page 81
show interfaces extensive (Gigabit Ethernet on MX Series Routers showing interface transmit statistics configuration) on page 82
show interfaces brief (Gigabit Ethernet) on page 82
show interfaces detail (Gigabit Ethernet) on page 83
show interfaces extensive (Gigabit Ethernet IQ2) on page 84
show interfaces (Gigabit Ethernet Unnumbered Interface) on page 87
show interfaces (ACI Interface Set Configured) on page 87

Output Fields

Table 5 on page 67 describes the output fields for the **show interfaces** (Gigabit Ethernet) command. Output fields are listed in the approximate order in which they appear. For Gigabit Ethernet IQ and IQE PICs, the traffic and MAC statistics vary by interface type. For more information, see Table 6 on page 80.

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields

Field Name	Field Description	Level of Output
Physical Interface		
Physical interface	Name of the physical interface.	All levels
Enabled	State of the interface. Possible values are described in the "Enabled Field" section under *Common Output Fields Description*.	All levels
Interface index	Index number of the physical interface, which reflects its initialization sequence.	**detail extensive** none
SNMP ifIndex	SNMP index number for the physical interface.	**detail extensive** none
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**
Link-level type	Encapsulation being used on the physical interface.	All levels
MTU	Maximum transmission unit size on the physical interface.	All levels
Speed	Speed at which the interface is running.	All levels
Loopback	Loopback status: **Enabled** or **Disabled**. If loopback is enabled, type of loopback: **Local** or **Remote**.	All levels
Source filtering	Source filtering status: **Enabled** or **Disabled**.	All levels
LAN-PHY mode	10-Gigabit Ethernet interface operating in Local Area Network Physical Layer Device (LAN PHY) mode. LAN PHY allows 10-Gigabit Ethernet wide area links to use existing Ethernet applications.	All levels
WAN-PHY mode	10-Gigabit Ethernet interface operating in Wide Area Network Physical Layer Device (WAN PHY) mode. WAN PHY allows 10-Gigabit Ethernet wide area links to use fiber-optic cables and other devices intended for SONET/SDH.	All levels
Unidirectional	Unidirectional link mode status for 10-Gigabit Ethernet interface: **Enabled** or **Disabled** for parent interface; **Rx-only** or **Tx-only** for child interfaces.	All levels
Flow control	Flow control status: **Enabled** or **Disabled**.	All levels
Auto-negotiation	(Gigabit Ethernet interfaces) Autonegotiation status: **Enabled** or **Disabled**.	All levels
Remote-fault	(Gigabit Ethernet interfaces) Remote fault status: • **Online**—Autonegotiation is manually configured as online. • **Offline**—Autonegotiation is manually configured as offline.	All levels
Device flags	Information about the physical device. Possible values are described in the "Device Flags" section under *Common Output Fields Description*.	All levels
Interface flags	Information about the interface. Possible values are described in the "Interface Flags" section under *Common Output Fields Description*.	All levels

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Link flags	Information about the link. Possible values are described in the "Links Flags" section under *Common Output Fields Description*.	All levels
Wavelength	(10-Gigabit Ethernet dense wavelength-division multiplexing [DWDM] interfaces) Displays the configured wavelength, in nanometers (nm).	All levels
Frequency	(10-Gigabit Ethernet DWDM interfaces only) Displays the frequency associated with the configured wavelength, in terahertz (THz).	All levels
CoS queues	Number of CoS queues configured.	**detail extensive** none
Schedulers	(Gigabit Ethernet intelligent queuing 2 [IQ2] interfaces only) Number of CoS schedulers configured.	**extensive**
Hold-times	Current interface hold-time up and hold-time down, in milliseconds (ms).	**detail extensive**
Current address	Configured MAC address.	**detail extensive** none
Hardware address	Hardware MAC address.	**detail extensive** none
Last flapped	Date, time, and how long ago the interface went from down to up. The format is **Last flapped:** ***year-month-day hour:minute:second:timezone*** **(*hour:minute:second* ago)**. For example, **Last flapped: 2002-04-26 10:52:40 PDT (04:33:20 ago).**	**detail extensive** none
Input Rate	Input rate in bits per second (bps) and packets per second (pps). The value in this field also includes the Layer 2 overhead bytes for ingress traffic on Ethernet interfaces if you enable accounting of Layer 2 overhead at the PIC level or the logical interface level.	None
Output Rate	Output rate in bps and pps. The value in this field also includes the Layer 2 overhead bytes for egress traffic on Ethernet interfaces if you enable accounting of Layer 2 overhead at the PIC level or the logical interface level.	None
Statistics last cleared	Time when the statistics for the interface were last set to zero.	**detail extensive**
Egress account overhead	Layer 2 overhead in bytes that is accounted in the interface statistics for egress traffic.	**detail extensive**
Ingress account overhead	Layer 2 overhead in bytes that is accounted in the interface statistics for ingress traffic.	**detail extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Traffic statistics	Number and rate of bytes and packets received and transmitted on the physical interface. • **Input bytes**—Number of bytes received on the interface. The value in this field also includes the Layer 2 overhead bytes for ingress traffic on Ethernet interfaces if you enable accounting of Layer 2 overhead at the PIC level or the logical interface level. • **Output bytes**—Number of bytes transmitted on the interface. The value in this field also includes the Layer 2 overhead bytes for egress traffic on Ethernet interfaces if you enable accounting of Layer 2 overhead at the PIC level or the logical interface level. • **Input packets**—Number of packets received on the interface. • **Output packets**—Number of packets transmitted on the interface. Gigabit Ethernet and 10-Gigabit Ethernet IQ PICs count the overhead and CRC bytes. For Gigabit Ethernet IQ PICs, the input byte counts vary by interface type. For more information, see Table 31 under the *show interfaces (10-Gigabit Ethernet)* command.	**detail extensive**
Input errors	Input errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious: • **Errors**—Sum of the incoming frame aborts and FCS errors. • **Drops**—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism. • **Framing errors**—Number of packets received with an invalid frame checksum (FCS). • **Runts**—Number of frames received that are smaller than the runt threshold. • **Policed discards**—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that Junos OS does not handle. • **L3 incompletes**—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded. L3 incomplete errors can be ignored by configuring the **ignore-l3-incompletes** statement. • **L2 channel errors**—Number of times the software did not find a valid logical interface for an incoming frame. • **L2 mismatch timeouts**—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable. • **FIFO errors**—Number of FIFO errors in the receive direction that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning. • **Resource errors**—Sum of transmit drops.	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Output errors	Output errors on the interface. The following paragraphs explain the counters whose meaning might not be obvious: • **Carrier transitions**—Number of times the interface has gone from **down** to **up**. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning. • **Errors**—Sum of the outgoing frame aborts and FCS errors. • **Drops**—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism. NOTE: Due to accounting space limitations on certain Type 3 FPCs (which are supported in M320 and T640 routers), the **Drops** field does not always use the correct value for queue 6 or queue 7 for interfaces on 10-port 1-Gigabit Ethernet PICs. • **Collisions**—Number of Ethernet collisions. The Gigabit Ethernet PIC supports only full-duplex operation, so for Gigabit Ethernet PICs, this number should always remain 0. If it is nonzero, there is a software bug. • **Aged packets**—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware. • **FIFO errors**—Number of FIFO errors in the send direction as reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning. • **HS link CRC errors**—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces. • **MTU errors**—Number of packets whose size exceeded the MTU of the interface. • **Resource errors**—Sum of transmit drops.	**extensive**
Egress queues	Total number of egress queues supported on the specified interface.	**detail extensive**
Queue counters (Egress)	CoS queue number and its associated user-configured forwarding class name. • **Queued packets**—Number of queued packets. • **Transmitted packets**—Number of transmitted packets. • **Dropped packets**—Number of packets dropped by the ASIC's RED mechanism. NOTE: Due to accounting space limitations on certain Type 3 FPCs (which are supported in M320 and T640 routers), the **Dropped packets** field does not always display the correct value for queue 6 or queue 7 for interfaces on 10-port 1-Gigabit Ethernet PICs.	**detail extensive**
Ingress queues	Total number of ingress queues supported on the specified interface. Displayed on IQ2 interfaces.	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Queue counters (Ingress)	CoS queue number and its associated user-configured forwarding class name. Displayed on IQ2 interfaces. • **Queued packets**—Number of queued packets. • **Transmitted packets**—Number of transmitted packets. • **Dropped packets**—Number of packets dropped by the ASIC's RED mechanism.	**extensive**
Active alarms and Active defects	Ethernet-specific defects that can prevent the interface from passing packets. When a defect persists for a certain amount of time, it is promoted to an alarm. Based on the router configuration, an alarm can ring the red or yellow alarm bell on the router, or turn on the red or yellow alarm LED on the craft interface. These fields can contain the value **None** or **Link**. • **None**—There are no active defects or alarms. • **Link**—Interface has lost its link state, which usually means that the cable is unplugged, the far-end system has been turned off, or the PIC is malfunctioning.	**detail extensive** none
Interface transmit statistics	(On MX Series devices) Status of the **interface-transmit-statistics** configuration: Enabled or Disabled. • **Enabled**—When the **interface-transmit-statistics** statement is included in the configuration. If this is configured, the interface statistics show the actual transmitted load on the interface. • **Disabled**—When the **interface-transmit-statistics** statement is not included in the configuration. If this is not configured, the interface statistics show the offered load on the interface.	**detail extensive**
OTN FEC statistics	The forward error correction (FEC) counters provide the following statistics: • **Corrected Errors**—The count of corrected errors in the last second. • **Corrected Error Ratio**—The corrected error ratio in the last 25 seconds. For example, 1e-7 is 1 error per 10 million bits.	**detail extensive**
PCS statistics	(10-Gigabit Ethernet interfaces) Displays Physical Coding Sublayer (PCS) fault conditions from the WAN PHY or the LAN PHY device. • **Bit errors**—High bit error rate. Indicates the number of bit errors when the PCS receiver is operating in normal mode. • **Errored blocks**—Loss of block lock. The number of errored blocks when the PCS receiver is operating in normal mode.	**detail extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output

MAC statistics	**Receive** and **Transmit** statistics reported by the PIC's MAC subsystem, including the following:
	• **Total octets** and **total packets**—Total number of octets and packets. For Gigabit Ethernet IQ PICs, the received octets count varies by interface type. For more information, see Table 31 under the *show interfaces (10-Gigabit Ethernet)* command.
	• **Unicast packets, Broadcast packets,** and **Multicast packets**—Number of unicast, broadcast, and multicast packets.
	• **CRC/Align errors**—Total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error).
	• **FIFO error**—Number of FIFO errors that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC or a cable is probably malfunctioning.
	• **MAC control frames**—Number of MAC control frames.
	• **MAC pause frames**—Number of MAC control frames with **pause** operational code.
	• **Oversized frames**—There are two possible conditions regarding the number of oversized frames:
	  ◦ Packet length exceeds 1518 octets, or
	  ◦ Packet length exceeds MRU
	• **Jabber frames**—Number of frames that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition in which any packet exceeds 20 ms. The allowed range to detect jabber is from 20 ms to 150 ms.
	• **Fragment frames**—Total number of packets that were less than 64 octets in length (excluding framing bits, but including FCS octets) and had either an FCS error or an alignment error. Fragment frames normally increment because both runts (which are normal occurrences caused by collisions) and noise hits are counted.
	• **VLAN tagged frames**—Number of frames that are VLAN tagged. The system uses the TPID of 0x8100 in the frame to determine whether a frame is tagged or not.
	NOTE: The 20-port Gigabit Ethernet MIC (MIC-3D-20GE-SFP) does not have hardware counters for VLAN frames. Therefore, the **VLAN tagged frames** field displays 0 when the **show interfaces** command is executed on a 20-port Gigabit Ethernet MIC. In other words, the number of VLAN tagged frames cannot be determined for the 20-port Gigabit Ethernet MIC.
	• **Code violations**—Number of times an event caused the PHY to indicate “Data reception error” or “invalid data symbol error.”
		extensive

OTN Received Overhead Bytes	APS/PCC0: 0x02, APS/PCC1: 0x11, APS/PCC2: 0x47, APS/PCC3: 0x58 Payload Type: 0x08	**extensive**
OTN Transmitted Overhead Bytes	APS/PCC0: 0x00, APS/PCC1: 0x00, APS/PCC2: 0x00, APS/PCC3: 0x00 Payload Type: 0x08	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Filter statistics	**Receive** and **Transmit** statistics reported by the PIC's MAC address filter subsystem. The filtering is done by the content-addressable memory (CAM) on the PIC. The filter examines a packet's source and destination MAC addresses to determine whether the packet should enter the system or be rejected. • **Input packet count**—Number of packets received from the MAC hardware that the filter processed. • **Input packet rejects**—Number of packets that the filter rejected because of either the source MAC address or the destination MAC address. • **Input DA rejects**—Number of packets that the filter rejected because the destination MAC address of the packet is not on the accept list. It is normal for this value to increment. When it increments very quickly and no traffic is entering the router from the far-end system, either there is a bad ARP entry on the far-end system, or multicast routing is not on and the far-end system is sending many multicast packets to the local router (which the router is rejecting). • **Input SA rejects**—Number of packets that the filter rejected because the source MAC address of the packet is not on the accept list. The value in this field should increment only if source MAC address filtering has been enabled. If filtering is enabled, if the value increments quickly, and if the system is not receiving traffic that it should from the far-end system, it means that the user-configured source MAC addresses for this interface are incorrect. • **Output packet count**—Number of packets that the filter has given to the MAC hardware. • **Output packet pad count**—Number of packets the filter padded to the minimum Ethernet size (60 bytes) before giving the packet to the MAC hardware. Usually, padding is done only on small ARP packets, but some very small IP packets can also require padding. If this value increments rapidly, either the system is trying to find an ARP entry for a far-end system that does not exist or it is misconfigured. • **Output packet error count**—Number of packets with an indicated error that the filter was given to transmit. These packets are usually aged packets or are the result of a bandwidth problem on the FPC hardware. On a normal system, the value of this field should not increment. • **CAM destination filters, CAM source filters**—Number of entries in the CAM dedicated to destination and source MAC address filters. There can only be up to 64 source entries. If source filtering is disabled, which is the default, the values for these fields should be 0.	**extensive**
PMA PHY	(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET error information: • **Seconds**—Number of seconds the defect has been active. • **Count**—Number of times that the defect has gone from inactive to active. • **State**—State of the error. Any state other than **OK** indicates a problem. Subfields are: • **PHY Lock**—Phase-locked loop • **PHY Light**—Loss of optical signal	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
WIS section	(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET error information: • **Seconds**—Number of seconds the defect has been active. • **Count**—Number of times that the defect has gone from inactive to active. • **State**—State of the error. Any state other than **OK** indicates a problem. Subfields are: • **BIP-B1**—Bit interleaved parity for SONET section overhead • **SEF**—Severely errored framing • **LOL**—Loss of light • **LOF**—Loss of frame • **ES-S**—Errored seconds (section) • **SES-S**—Severely errored seconds (section) • **SEFS-S**—Severely errored framing seconds (section)	**extensive**
WIS line	(10-Gigabit Ethernet interfaces, WAN PHY mode) Active alarms and defects, plus counts of specific SONET errors with detailed information: • **Seconds**—Number of seconds the defect has been active. • **Count**—Number of times that the defect has gone from inactive to active. • **State**—State of the error. Any state other than **OK** indicates a problem. Subfields are: • **BIP-B2**—Bit interleaved parity for SONET line overhead • **REI-L**—Remote error indication (near-end line) • **RDI-L**—Remote defect indication (near-end line) • **AIS-L**—Alarm indication signal (near-end line) • **BERR-SF**—Bit error rate fault (signal failure) • **BERR-SD**—Bit error rate defect (signal degradation) • **ES-L**—Errored seconds (near-end line) • **SES-L**—Severely errored seconds (near-end line) • **UAS-L**—Unavailable seconds (near-end line) • **ES-LFE**—Errored seconds (far-end line) • **SES-LFE**—Severely errored seconds (far-end line) • **UAS-LFE**—Unavailable seconds (far-end line)	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
WIS path	(10-Gigabit Ethernet interfaces, WAN PHY mode) Active alarms and defects, plus counts of specific SONET errors with detailed information: • **Seconds**—Number of seconds the defect has been active. • **Count**—Number of times that the defect has gone from inactive to active. • **State**—State of the error. Any state other than **OK** indicates a problem. Subfields are: • **BIP-B3**—Bit interleaved parity for SONET section overhead • **REI-P**—Remote error indication • **LOP-P**—Loss of pointer (path) • **AIS-P**—Path alarm indication signal • **RDI-P**—Path remote defect indication • **UNEQ-P**—Path unequipped • **PLM-P**—Path payload (signal) label mismatch • **ES-P**—Errored seconds (near-end STS path) • **SES-P**—Severely errored seconds (near-end STS path) • **UAS-P**—Unavailable seconds (near-end STS path) • **SES-PFE**—Severely errored seconds (far-end STS path) • **UAS-PFE**—Unavailable seconds (far-end STS path)	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output

Autonegotiation information	Information about link autonegotiation.
	• **Negotiation status:**
	  • **Incomplete**—Ethernet interface has the speed or link mode configured.
	  • **No autonegotiation**—Remote Ethernet interface has the speed or link mode configured, or does not perform autonegotiation.
	  • **Complete**—Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.
	• **Link partner status**—**OK** when Ethernet interface is connected to a device that performs autonegotiation and the autonegotiation process is successful.
	• **Link partner**—Information from the remote Ethernet device:
	  • **Link mode**—Depending on the capability of the link partner, either **Full-duplex** or **Half-duplex**.
	  • **Flow control**—Types of flow control supported by the link partner. For Gigabit Ethernet interfaces, types are **Symmetric** (link partner supports **PAUSE** on receive and transmit), **Asymmetric** (link partner supports **PAUSE** on transmit), **Symmetric/Asymmetric** (link partner supports **PAUSE** on receive and transmit or only **PAUSE** on transmit), and **None** (link partner does not support flow control).
	  • **Remote fault**—Remote fault information from the link partner—**Failure** indicates a receive link error. **OK** indicates that the link partner is receiving. **Negotiation error** indicates a negotiation error. **Offline** indicates that the link partner is going offline.
	• **Local resolution**—Information from the local Ethernet device:
	  • **Flow control**—Types of flow control supported by the local device. For Gigabit Ethernet interfaces, advertised capabilities are **Symmetric/Asymmetric** (local device supports **PAUSE** on receive and transmit or only **PAUSE** on receive) and **None** (local device does not support flow control). Depending on the result of the negotiation with the link partner, local resolution flow control type will display **Symmetric** (local device supports **PAUSE** on receive and transmit), **Asymmetric** (local device supports **PAUSE** on receive), and **None** (local device does not support flow control).
	  • **Remote fault**—Remote fault information. **Link OK** (no error detected on receive), **Offline** (local interface is offline), and **Link Failure** (link error detected on receive).
		extensive

Received path trace, Transmitted path trace	(10-Gigabit Ethernet interfaces, WAN PHY mode) SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other router manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the router at the other end of the fiber. The transmitted path trace value is the message that this router transmits.	**extensive**
Packet Forwarding Engine configuration	Information about the configuration of the Packet Forwarding Engine: • **Destination slot**—FPC slot number.	**extensive**

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
CoS information	Information about the CoS queue for the physical interface. • **CoS transmit queue**—Queue number and its associated user-configured forwarding class name. • **Bandwidth %**—Percentage of bandwidth allocated to the queue. • **Bandwidth bps**—Bandwidth allocated to the queue (in bps). • **Buffer %**—Percentage of buffer space allocated to the queue. • **Buffer usec**—Amount of buffer space allocated to the queue, in microseconds. This value is nonzero only if the buffer size is configured in terms of time. • **Priority**—Queue priority: **low** or **high**. • **Limit**—Displayed if rate limiting is configured for the queue. Possible values are **none** and **exact**. If **exact** is configured, the queue transmits only up to the configured bandwidth, even if excess bandwidth is available. If **none** is configured, the queue transmits beyond the configured bandwidth if bandwidth is available.	**extensive**
Logical Interface		
Logical interface	Name of the logical interface.	All levels
Index	Index number of the logical interface, which reflects its initialization sequence.	**detail extensive** none
SNMP ifIndex	SNMP interface index number for the logical interface.	**detail extensive** none
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**
Flags	Information about the logical interface. Possible values are described in the "Logical Interface Flags" section under *Common Output Fields Description*.	All levels

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
VLAN-Tag	Rewrite profile applied to incoming or outgoing frames on the outer (**Out**) VLAN tag or for both the outer and inner (**In**) VLAN tags. • **push**—An outer VLAN tag is pushed in front of the existing VLAN tag. • **pop**—The outer VLAN tag of the incoming frame is removed. • **swap**—The outer VLAN tag of the incoming frame is overwritten with the user-specified VLAN tag information. • **push**—An outer VLAN tag is pushed in front of the existing VLAN tag. • **push-push**—Two VLAN tags are pushed in from the incoming frame. • **swap-push**—The outer VLAN tag of the incoming frame is replaced by a user-specified VLAN tag value. A user-specified outer VLAN tag is pushed in front. The outer tag becomes an inner tag in the final frame. • **swap-swap**—Both the inner and the outer VLAN tags of the incoming frame are replaced by the user-specified VLAN tag value. • **pop-swap**—The outer VLAN tag of the incoming frame is removed, and the inner VLAN tag of the incoming frame is replaced by the user-specified VLAN tag value. The inner tag becomes the outer tag in the final frame. • **pop-pop**—Both the outer and inner VLAN tags of the incoming frame are removed.	**brief detail extensive** none
Demux	IP demultiplexing (demux) value that appears if this interface is used as the demux underlying interface. The output is one of the following: • Source Family Inet • Destination Family Inet	**detail extensive** none
Encapsulation	Encapsulation on the logical interface.	All levels
ACI VLAN: Dynamic Profile	Name of the dynamic profile that defines the agent circuit identifier (ACI) interface set. If configured, the ACI interface set enables the underlying Ethernet interface to create dynamic VLAN subscriber interfaces based on ACI information.	**brief detail extensive** none
Protocol	Protocol family. Possible values are described in the “Protocol Field” section under *Common Output Fields Description*.	**detail extensive** none
MTU	Maximum transmission unit size on the logical interface.	**detail extensive** none
Dynamic Profile	(MX Series routers with Trio MPCs only) Name of the dynamic profile that was used to create this interface configured with a Point-to-Point Protocol over Ethernet (PPPoE) family.	**detail extensive** none
Service Name Table	(MX Series routers with Trio MPCs only) Name of the service name table for the interface configured with a PPPoE family.	**detail extensive** none
Max Sessions	(MX Series routers with Trio MPCs only) Maximum number of PPPoE logical interfaces that can be activated on the underlying interface.	**detail extensive** none

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Duplicate Protection	(MX Series routers with Trio MPCs only) State of PPPoE duplicate protection: **On** or **Off**. When duplicate protection is configured for the underlying interface, a dynamic PPPoE logical interface cannot be activated when an existing active logical interface is present for the same PPPoE client.	**detail extensive** none
Direct Connect	State of the configuration to ignore DSL Forum VSAs: **On** or **Off**. When configured, the router ignores any of these VSAs received from a directly connected CPE device on the interface.	**detail extensive** none
AC Name	Name of the access concentrator.	**detail extensive** none
Maximum labels	Maximum number of MPLS labels configured for the MPLS protocol family on the logical interface.	**detail extensive** none
Traffic statistics	Number and rate of bytes and packets received and transmitted on the specified interface set. • **Input bytes, Output bytes**—Number of bytes received and transmitted on the interface set. The value in this field also includes the Layer 2 overhead bytes for ingress or egress traffic on Ethernet interfaces if you enable accounting of Layer 2 overhead at the PIC level or the logical interface level. • **Input packets, Output packets**—Number of packets received and transmitted on the interface set.	**detail extensive**
IPv6 transit statistics	Number of IPv6 transit bytes and packets received and transmitted on the logical interface if IPv6 statistics tracking is enabled.	**extensive**
Local statistics	Number and rate of bytes and packets destined to the router.	**extensive**
Transit statistics	Number and rate of bytes and packets transiting the switch. NOTE: For Gigabit Ethernet intelligent queuing 2 (IQ2) interfaces, the logical interface egress statistics might not accurately reflect the traffic on the wire when output shaping is applied. Traffic management output shaping might drop packets after they are tallied by the **Output bytes** and **Output packets** interface counters. However, correct values display for both of these egress statistics when per-unit scheduling is enabled for the Gigabit Ethernet IQ2 physical interface, or when a single logical interface is actively using a shared scheduler.	**extensive**
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**
Route Table	Route table in which the logical interface address is located. For example, **0** refers to the routing table inet.0.	**detail extensive** none
Flags	Information about protocol family flags. Possible values are described in the "Family Flags" section under *Common Output Fields Description*.	**detail extensive**
Donor interface	(Unnumbered Ethernet) Interface from which an unnumbered Ethernet interface borrows an IPv4 address.	**detail extensive** none

Copyright © 2014, Juniper Networks, Inc.

Table 5: show interfaces Gigabit Ethernet Output Fields *(continued)*

Field Name	Field Description	Level of Output
Preferred source address	(Unnumbered Ethernet) Secondary IPv4 address of the donor loopback interface that acts as the preferred source address for the unnumbered Ethernet interface.	**detail extensive** none
Input Filters	Names of any input filters applied to this interface. If you specify a precedence value for any filter in a dynamic profile, filter precedence values appear in parentheses next to all interfaces.	**detail extensive**
Output Filters	Names of any output filters applied to this interface. If you specify a precedence value for any filter in a dynamic profile, filter precedence values appear in parentheses next to all interfaces.	**detail extensive**
Mac-Validate Failures	Number of MAC address validation failures for packets and bytes. This field is displayed when MAC address validation is enabled for the logical interface.	**detail extensive** none
Addresses, Flags	Information about the address flags. Possible values are described in the "Addresses Flags" section under *Common Output Fields Description*.	**detail extensive** none
protocol-family	Protocol family configured on the logical interface. If the protocol is **inet**, the IP address of the interface is also displayed.	**brief**
Flags	Information about the address flag. Possible values are described in the "Addresses Flags" section under *Common Output Fields Description*.	**detail extensive** none
Destination	IP address of the remote side of the connection.	**detail extensive** none
Local	IP address of the logical interface.	**detail extensive** none
Broadcast	Broadcast address of the logical interface.	**detail extensive** none
Generation	Unique number for use by Juniper Networks technical support only.	**detail extensive**

Table 6: Gigabit Ethernet IQ PIC Traffic and MAC Statistics by Interface Type

Interface Type	Sample Command	Byte and Octet Counts Include	Comments
Inbound physical interface	**show interfaces ge-0/3/0 extensive**	Traffic statistics: Input bytes: 496 bytes per packet, representing the Layer 2 packet MAC statistics: Received octets: 500 bytes per packet, representing the Layer 2 packet + 4 bytes	The additional 4 bytes are for the CRC.
Inbound logical interface	**show interfaces ge-0/3/0.50 extensive**	Traffic statistics: Input bytes: 478 bytes per packet, representing the Layer 3 packet	

Copyright © 2014, Juniper Networks, Inc.

Table 6: Gigabit Ethernet IQ PIC Traffic and MAC Statistics by Interface Type *(continued)*

Interface Type	Sample Command	Byte and Octet Counts Include	Comments
Outbound physical interface	**show interfaces ge-0/0/0 extensive**	Traffic statistics: Input bytes: 490 bytes per packet, representing the Layer 3 packet + 12 bytes MAC statistics: Received octets: 478 bytes per packet, representing the Layer 3 packet	For input bytes, the additional 12 bytes include 6 bytes for the destination MAC address plus 4 bytes for VLAN plus 2 bytes for the Ethernet type.
Outbound logical interface	**show interfaces ge-0/0/0.50 extensive**	Traffic statistics: Input bytes: 478 bytes per packet, representing the Layer 3 packet	

Sample Output

show interfaces (Gigabit Ethernet)

```
user@host> show interfaces ge-3/0/2
Physical interface: ge-3/0/2, Enabled, Physical link is Up
  Interface index: 167, SNMP ifIndex: 35
  Link-level type: 52, MTU: 1522, Speed: 1000mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled
  Remote fault: Online
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  CoS queues     : 4 supported, 4 maximum usable queues
  Current address: 00:05:85:4a:e9:7c, Hardware address: 00:05:85:4a:e9:7c
  Last flapped   : 2006-08-10 17:25:10 PDT (00:01:08 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
  Ingress rate at Packet Forwarding Engine      : 0 bps (0 pps)
  Ingress drop rate at Packet Forwarding Engine : 0 bps (0 pps)
  Active alarms  : None
  Active defects : None

  Logical interface ge-3/0/2.0 (Index 72) (SNMP ifIndex 69)
    Flags: SNMP-Traps 0x4000
    VLAN-Tag [ 0x8100.512 0x8100.513 ] In(pop-swap 0x8100.530) Out(swap-push
    0x8100.512 0x8100.513)
    Encapsulation: VLAN-CCC
    Egress account overhead: 100
    Ingress account overhead: 90
    Input packets : 0
    Output packets: 0
    Protocol ccc, MTU: 1522
      Flags: Is-Primary
```

show interfaces (Gigabit Ethernet on MX Series Routers)

```
user@host> show interfaces ge-2/2/2
Physical interface: ge-2/2/2, Enabled, Physical link is Up
  Interface index: 156, SNMP ifIndex: 188
  Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps, MAC-REWRITE Error: None,
 Loopback: Disabled,
```

Copyright © 2014, Juniper Networks, Inc.

```
  Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
Remote fault: Online
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : None
  CoS queues     : 8 supported, 4 maximum usable queues
  Schedulers     : 0
  Current address: 00:1f:12:b7:d7:c0, Hardware address: 00:1f:12:b7:d6:76
  Last flapped   : 2008-09-05 16:44:30 PDT (3d 01:04 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 0 bps (0 pps)
  Active alarms  : None
  Active defects : None
  Logical interface ge-2/2/2.0 (Index 82) (SNMP ifIndex 219)
    Flags: SNMP-Traps 0x20000000 Encapsulation: Ethernet-Bridge
    Egress account overhead: 100
    Ingress account overhead: 90
    Input packets : 0
    Output packets: 0
     Protocol aenet, AE bundle: ae0.0    Link Index: 4
```

show interfaces extensive (Gigabit Ethernet on MX Series Routers showing interface transmit statistics configuration)

```
user@host> show interfaces ge-2/1/2 extensive | match "output|interface"
Physical interface: ge-2/1/2, Enabled, Physical link is Up
  Interface index: 151, SNMP ifIndex: 530, Generation: 154
  Interface flags: SNMP-Traps Internal: 0x4000
   Output bytes  :         240614363944            772721536 bps
   Output packets:           3538446506              1420444 pps
    Direction : Output
  Interface transmit statistics: Enabled

  Logical interface ge-2/1/2.0 (Index 331) (SNMP ifIndex 955) (Generation 146)
     Output bytes  :         195560312716            522726272 bps
     Output packets:           4251311146              1420451 pps
```

show interfaces brief (Gigabit Ethernet)

```
user@host> show interfaces ge-3/0/2 brief
Physical interface: ge-3/0/2, Enabled, Physical link is Up
  Link-level type: 52, MTU: 1522, Speed: 1000mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
  Remote fault: Online
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : None

  Logical interface ge-3/0/2.0
    Flags: SNMP-Traps 0x4000
    VLAN-Tag [ 0x8100.512 0x8100.513 ] In(pop-swap 0x8100.530) Out(swap-push
    0x8100.512 0x8100.513)
    Encapsulation: VLAN-CCC
    ccc

  Logical interface ge-3/0/2.32767
    Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x0000.0 ]  Encapsulation: ENET2
```


Copyright © 2014, Juniper Networks, Inc.

show interfaces detail (Gigabit Ethernet)

```
user@host> show interfaces ge-3/0/2 detail
Physical interface: ge-3/0/2, Enabled, Physical link is Up
  Interface index: 167, SNMP ifIndex: 35, Generation: 177
  Link-level type: 52, MTU: 1522, Speed: 1000mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
  Remote fault: Online
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : None
  CoS queues     : 4 supported, 4 maximum usable queues
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:05:85:4a:e9:7c, Hardware address: 00:05:85:4a:e9:7c
  Last flapped   : 2006-08-09 17:17:00 PDT (01:31:33 ago)
  Statistics last cleared: Never
  Traffic statistics:
   Input  bytes  :                   0                   0 bps
   Output bytes  :                   0                   0 bps
   Input  packets:                   0                   0 pps
   Output packets:                   0                   0 pps
  Ingress traffic statistics at Packet Forwarding Engine:
   Input  bytes  :                   0                   0 bps
   Input  packets:                   0                   0 pps
   Drop   bytes  :                   0                   0 bps
   Drop   packets:                   0                   0 pps
  Ingress queues: 4 supported, 4 in use
  Queue counters:       Queued packets  Transmitted packets      Dropped packets

    0 best-effort                   0                   0                   0

    1 expedited-fo                  0                   0                   0

    2 assured-forw                  0                   0                   0

    3 network-cont                  0                   0                   0

  Egress queues: 4 supported, 4 in use
  Queue counters:       Queued packets  Transmitted packets      Dropped packets

    0 best-effort                   0                   0                   0

    1 expedited-fo                  0                   0                   0

    2 assured-forw                  0                   0                   0

    3 network-cont                  0                   0                   0

  Active alarms  : None
  Active defects : None

  Logical interface ge-3/0/2.0 (Index 72) (SNMP ifIndex 69) (Generation 140)
    Flags: SNMP-Traps 0x4000
    VLAN-Tag [0x8100.512 0x8100.513 ] In(pop-swap 0x8100.530)
Out(swap-push 0x8100.512 0x8100.513)
    Encapsulation: VLAN-CCC
    Egress account overhead: 100
    Ingress account overhead: 90
    Traffic statistics:
     Input  bytes  :                   0
     Output bytes  :                   0
```

```
    Input  packets:                  0
    Output packets:                  0
   Local statistics:
    Input  bytes  :                  0
    Output bytes  :                  0
    Input  packets:                  0
    Output packets:                  0
   Transit statistics:
    Input  bytes  :                  0                    0 bps
    Output bytes  :                  0                    0 bps
    Input  packets:                  0                    0 pps
    Output packets:                  0                    0 pps
   Protocol ccc, MTU: 1522, Generation: 149, Route table: 0
     Flags: Is-Primary

  Logical interface ge-3/0/2.32767 (Index 71) (SNMP ifIndex 70)
  (Generation 139)
    Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x0000.0 ]  Encapsulation: ENET2
    Traffic statistics:
     Input  bytes  :                 0
     Output bytes  :                 0
     Input  packets:                 0
     Output packets:                 0
    Local statistics:
     Input  bytes  :                 0
     Output bytes  :                 0
     Input  packets:                 0
     Output packets:                 0
    Transit statistics:
     Input  bytes  :                 0                    0 bps
     Output bytes  :                 0                    0 bps
     Input  packets:                 0                    0 pps
     Output packets:                 0                    0 pps
```

show interfaces extensive (Gigabit Ethernet IQ2)

```
user@host> show interfaces ge-7/1/3 extensive
Physical interface: ge-7/1/3, Enabled, Physical link is Up
  Interface index: 170, SNMP ifIndex: 70, Generation: 171
  Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
  Remote fault: Online
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4004000
  Link flags     : None
  CoS queues     : 8 supported, 4 maximum usable queues
  Schedulers     : 256
  Hold-times     : Up 0 ms, Down 0 ms
  Current address: 00:14:f6:30:5e:74, Hardware address: 00:14:f6:30:5e:74
  Last flapped   : 2007-11-07 21:31:41 PST (02:03:33 ago)
  Statistics last cleared: Never
  Traffic statistics:
   Input  bytes  :          38910844056                 7952 bps
   Output bytes  :              7174605                 8464 bps
   Input  packets:            418398473                   11 pps
   Output packets:                78903                   12 pps
   IPv6 transit statistics:
    Input  bytes  :                   0
    Output bytes  :                   0
    Input  packets:                   0
    Output packets:                   0
```


Copyright © 2014, Juniper Networks, Inc.

```
Ingress traffic statistics at Packet Forwarding Engine:
 Input  bytes  :          38910799145                 7952 bps
 Input  packets:            418397956                   11 pps
 Drop   bytes  :                    0                    0 bps
 Drop   packets:                    0                    0 pps
Input errors:
  Errors: 0, Drops: 0, Framing errors: 0, Runts: 0, Policed discards: 0,
  L3 incompletes: 0, L2 channel errors: 0, L2 mismatch timeouts: 0,
  FIFO errors: 0, Resource errors: 0
Output errors:
  Carrier transitions: 1, Errors: 0, Drops: 0, Collisions: 0, Aged packets: 0,

  FIFO errors: 0, HS link CRC errors: 0, MTU errors: 0, Resource errors: 0
Ingress queues: 4 supported, 4 in use
Queue counters:       Queued packets  Transmitted packets      Dropped packets

  0 best-effort            418390823            418390823                    0

  1 expedited-fo                   0                    0                    0

  2 assured-forw                   0                    0                    0

  3 network-cont                7133                 7133                    0

Egress queues: 4 supported, 4 in use
Queue counters:       Queued packets  Transmitted packets      Dropped packets

  0 best-effort                 1031                 1031                    0

  1 expedited-fo                   0                    0                    0

  2 assured-forw                   0                    0                    0

  3 network-cont               77872                77872                    0

Active alarms  : None
Active defects : None
MAC statistics:                      Receive         Transmit
  Total octets                    38910844056          7174605
  Total packets                     418398473            78903
  Unicast packets                408021893366             1026
  Broadcast packets                        10               12
  Multicast packets                 418398217            77865
  CRC/Align errors                          0                0
  FIFO errors                               0                0
  MAC control frames                        0                0
  MAC pause frames                          0                0
  Oversized frames                          0
  Jabber frames                             0
  Fragment frames                           0
  VLAN tagged frames                        0
  Code violations                           0  OTN Received Overhead Bytes:
  APS/PCC0: 0x02, APS/PCC1: 0x11, APS/PCC2: 0x47, APS/PCC3: 0x58
  Payload Type: 0x08
OTN Transmitted Overhead Bytes:
  APS/PCC0: 0x00, APS/PCC1: 0x00, APS/PCC2: 0x00, APS/PCC3: 0x00
  Payload Type: 0x08
Filter statistics:
  Input packet count               418398473
  Input packet rejects                   479
  Input DA rejects                       479
```

Copyright © 2014, Juniper Networks, Inc.

```
    Input SA rejects                          0
    Output packet count                                    78903
    Output packet pad count                                    0
    Output packet error count                                  0
    CAM destination filters: 0, CAM source filters: 0
  Autonegotiation information:
    Negotiation status: Complete
    Link partner:
        Link mode: Full-duplex, Flow control: Symmetric/Asymmetric,
        Remote fault: OK
    Local resolution:
        Flow control: Symmetric, Remote fault: Link OK
  Packet Forwarding Engine configuration:
    Destination slot: 7
  CoS information:
    Direction : Output
    CoS transmit queue          Bandwidth          Buffer     Priority   Limit
                                %            bps     %           usec
    0 best-effort              95      950000000    95              0
low    none
    3 network-control           5       50000000     5              0
low    none
    Direction : Input
    CoS transmit queue          Bandwidth          Buffer     Priority   Limit
                                %            bps     %           usec
    0 best-effort              95      950000000    95              0
low    none
    3 network-control           5       50000000     5              0
low    none

  Logical interface ge-7/1/3.0 (Index 70) (SNMP ifIndex 85) (Generation 150)
    Flags: SNMP-Traps Encapsulation: ENET2
    Traffic statistics:
     Input  bytes  :               812400
     Output bytes  :              1349206
     Input  packets:                 9429
     Output packets:                 9449
     IPv6 transit statistics:
      Input  bytes  :                   0
      Output bytes  :                   0
      Input  packets:                   0
      Output packets:                   0
    Local statistics:
     Input  bytes  :               812400
     Output bytes  :              1349206
     Input  packets:                 9429
     Output packets:                 9449
    Transit statistics:
     Input  bytes  :                   0                 7440 bps
     Output bytes  :                   0                 7888 bps
     Input  packets:                   0                   10 pps
     Output packets:                   0                   11 pps
     IPv6 transit statistics:
      Input  bytes  :                   0
      Output bytes  :                   0
      Input  packets:                   0
      Output packets:                   0
    Protocol inet, MTU: 1500, Generation: 169, Route table: 0
      Flags: Is-Primary, Mac-Validate-Strict
      Mac-Validate Failures: Packets: 0, Bytes: 0
      Addresses, Flags: Is-Preferred Is-Primary
```


Copyright © 2014, Juniper Networks, Inc.

```
    Input Filters: F1-ge-3/0/1.0-in, F3-ge-3/0/1.0-in
    Output Filters: F2-ge-3/0/1.0-out (53)
    Destination: 10.74.2/24, Local: 10.74.2.2, Broadcast: 10.74.2.255,
      Generation: 196
  Protocol multiservice, MTU: Unlimited, Generation: 170, Route table: 0
    Flags: Is-Primary
    Policer: Input: __default_arp_policer__
```

NOTE: For Gigabit Ethernet intelligent queuing 2 (IQ2) interfaces, the logical interface egress statistics displayed in the **show interfaces** command output might not accurately reflect the traffic on the wire when output shaping is applied. Traffic management output shaping might drop packets after they are tallied by the interface counters. For detailed information, see the description of the logical interface **Transit statistics** fields in Table 5 on page 67.

show interfaces (Gigabit Ethernet Unnumbered Interface)

```
user@host> show interfaces ge-3/2/0
Physical interface: ge-3/2/0, Enabled, Physical link is Up
  Interface index: 148, SNMP ifIndex: 50
  Link-level type: Ethernet, MTU: 1514, Speed: 1000mbps, Loopback: Disabled,
  Source filtering: Disabled, Flow control: Enabled, Auto-negotiation: Enabled,
  Remote fault: Online
  Device flags   : Present Running
  Interface flags: SNMP-Traps Internal: 0x4000
  Link flags     : None
  CoS queues     : 8 supported, 4 maximum usable queues
  Current address: 00:14:f6:11:26:f8, Hardware address: 00:14:f6:11:26:f8
  Last flapped   : 2006-10-27 04:42:23 PDT (08:01:52 ago)
  Input rate     : 0 bps (0 pps)
  Output rate    : 624 bps (1 pps)
  Active alarms  : None
  Active defects : None

  Logical interface ge-3/2/0.0 (Index 67) (SNMP ifIndex 85)
    Flags: SNMP-Traps Encapsulation: ENET2
    Input packets : 0
    Output packets: 6
    Protocol inet, MTU: 1500
      Flags: Unnumbered
      Donor interface: lo0.0 (Index 64)
      Preferred source address: 22.22.22.22
```

show interfaces (ACI Interface Set Configured)

```
user@host> show interfaces ge-1/0/0.4001
  Logical interface ge-1/0/0.4001 (Index 340) (SNMP ifIndex 548)
    Flags: SNMP-Traps 0x4000 VLAN-Tag [ 0x8100.4001 ]  Encapsulation: PPP-over-

    Ethernet
    ACI VLAN:
      Dynamic Profile: aci-vlan-set-profile
    PPPoE:
      Dynamic Profile: aci-vlan-pppoe-profile,
      Service Name Table: None,
      Max Sessions: 32000, Max Sessions VSA Ignore: Off,
      Duplicate Protection: On, Short Cycle Protection: Off,
      Direct Connect: Off,
      AC Name: nbc
```

Copyright © 2014, Juniper Networks, Inc.

```
Input packets : 9
Output packets: 8
Protocol multiservice, MTU: Unlimited
```


Copyright © 2014, Juniper Networks, Inc.

PART 4

Troubleshooting

- Ethernet on page 91
- Interface Diagnostics on page 95

Copyright © 2014, Juniper Networks, Inc.

Copyright © 2014, Juniper Networks, Inc.

CHAPTER 6

Ethernet

- traceroute ethernet

Copyright © 2014, Juniper Networks, Inc.

traceroute ethernet

Syntax

traceroute ethernet (*mac-address* | *mep-id*)
maintenance-association *ma-name*
maintenance-domain *md-name*
ttl *value*
<**wait** *seconds*>

Release Information

Command introduced in Junos OS Release 9.0.
mep-id option introduced in Junos OS Release 9.1.

Description

Triggers the linktrace protocol to trace the route between two maintenance points. The result of the traceroute protocol is stored in the path database. To display the path database, use the **show oam ethernet connectivity-fault-management path-database** command.

Before using the traceroute command, you can verify the remote MEP's MAC address using the **show oam ethernet connectivity-fault-management path-database** command.

Options

mac-address—Destination unicast MAC address of the remote maintenance point.

mep-id—MEP identifier of the remote maintenance point. The range of values is 1 through 8191.

maintenance-association ***ma-name***—Specifies an existing maintenance association from the set of configured maintenance associations.

maintenance-domain ***md-name***—Specifies an existing maintenance domain from the set of configured maintenance domains.

ttl ***value***—Number of hops to use in the linktrace request. The range is 1 to 255 hops. The default is 4.

wait ***seconds***—(Optional) Maximum time to wait for a response to the traceroute request. The range is 1 to 255 seconds. The default is 5.

Required Privilege Level

network

List of Sample Output

traceroute ethernet on page 93

Output Fields

Table 7 on page 92 lists the output fields for the **traceroute ethernet** command. Output fields are listed in the approximate order in which they appear.

Table 7: traceroute ethernet Output Fields

Field Name	Field Description
Linktrace to	MAC address of the destination maintenance point.
Interface	Local interface used to send the linktrace message (LTM).

Copyright © 2014, Juniper Networks, Inc.

Table 7: traceroute ethernet Output Fields *(continued)*

Field Name	Field Description
Maintenance Domain	Maintenance domain specified in the traceroute command.
Level	Maintenance domain level configured.
Maintenance Association	Maintenance association specified in the traceroute command.
Local Mep	The local maintenance end point identifier.
Transaction Identifier	4-byte identifier maintained by the MEP. Each LTM uses a transaction identifier. The transaction identifier is maintained globally across all Maintenance Domains. Use the transaction identifier to match an incoming linktrace response (LTR), with a previously sent LTM.
Hop	Sequential hop count of the linktrace path.
TTL	Number of hops remaining in the linktrace message. The time to live (TTL) is decremented at each hop.
Source MAC address	MAC address of the 802.1ag node responding to the LTM or the source MAC address of the LTR.
Next-hop MAC address	MAC address of the egress interface of the node to which the LTM is forwarded or the next-hop MAC address derived from the next egress identifier in the Egress-ID TLV of the LTR PDU.

Sample Output

traceroute ethernet

```
user@host> traceroute ethernet maintenance-domain md1 maintenance-association ma1
00:01:02:03:04:05
 Linktrace to 00:01:02:03:04:05, Interface : ge-5/0/0.0
       Maintenance Domain: MD1, Level: 7
       Maintenance Association: MA1, Local Mep: 1

       Hop     TTL      Source MAC address        Next hop MAC address
       Transaction Identifier:100001
       1       63       00:00:aa:aa:aa:aa         00:00:ab:ab:ab:ab
       2       62       00:00:bb:bb:bb:bb         00:00:bc:bc:bc:bc
       3       61       00:00:cc:cc:cc:cc         00:00:cd:cd:cd:cd
       4       60       00:01:02:03:04:05         00:00:00:00:00:00
```

Copyright © 2014, Juniper Networks, Inc.

Copyright © 2014, Juniper Networks, Inc.

CHAPTER 7

Interface Diagnostics

- Interface Diagnostics on page 95

Interface Diagnostics

You can use two diagnostic tools to test the physical layer connections of interfaces: loopback testing and bit error rate test (BERT) testing. Loopback testing enables you to verify the connectivity of a circuit. BERT testing enables you to identify poor signal quality on a circuit. This section contains the following topics:

- Configuring Loopback Testing on page 95
- Interface Diagnostics on page 97

Configuring Loopback Testing

Loopback testing allows you to verify the connectivity of a circuit. You can configure any of the following interfaces to execute a loopback test: Aggregated Ethernet, Fast Ethernet, Gigabit Ethernet, E1, E3, *N*xDS0, serial, SONET/SDH, T1, and T3.

The physical path of a network data circuit usually consists of segments interconnected by devices that repeat and regenerate the transmission signal. The transmit path on one device connects to the receive path on the next device. If a circuit fault occurs in the form of a line break or a signal corruption, you can isolate the problem by using a loopback test. Loopback tests allow you to isolate segments of the circuit and test them separately.

To do this, configure a *line loopback* on one of the routers. Instead of transmitting the signal toward the far-end device, the line loopback sends the signal back to the originating router. If the originating router receives back its own data link layer packets, you have verified that the problem is beyond the originating router. Next, configure a line loopback farther away from the local router. If this originating router does not receive its own data link layer packets, you can assume the problem is on one of the segments between the local router and the remote router's interface card. In this case, the next troubleshooting step is to configure a line loopback closer to the local router to find the source of the problem.

There are several types of loopback testing supported by the Junos OS, as follows:

- DCE local—Loops packets back on the local DCE.
- DCE remote—Loops packets back on the remote DCE.

Copyright © 2014, Juniper Networks, Inc.

- Local—Useful for troubleshooting physical PIC errors. Configuring local loopback on an interface allows transmission of packets to the channel service unit (CSU) and then to the circuit toward the far-end device. The interface receives its own transmission, which includes data and timing information, on the local router's PIC. The data received from the CSU is ignored. To test a local loopback, issue the **show interfaces *interface-name*** command. If PPP keepalives transmitted on the interface are received by the PIC, the **Device Flags** field contains the output **Loop-Detected**.
- Payload—Useful for troubleshooting the physical circuit problems between the local router and the remote router. A payload loopback loops data only (without clocking information) on the remote router's PIC. With payload loopback, overhead is recalculated.
- Remote—Useful for troubleshooting the physical circuit problems between the local router and the remote router. A remote loopback loops packets, including both data and timing information, back on the remote router's interface card. A router at one end of the circuit initiates a remote loopback toward its remote partner. When you configure a remote loopback, the packets received from the physical circuit and CSU are received by the interface. Those packets are then retransmitted by the PIC back toward the CSU and the circuit. This loopback tests all the intermediate transmission segments.

Table 8 on page 96 shows the loopback modes supported on the various interface types.

Table 8: Loopback Modes by Interface Type

Interface	Loopback Modes	Usage Guidelines
Aggregated Ethernet, Fast Ethernet, Gigabit Ethernet	Local	*Configuring Ethernet Loopback Capability*
Circuit Emulation E1	Local and remote	*Configuring E1 Loopback Capability*
Circuit Emulation T1	Local and remote	*Configuring T1 Loopback Capability*
E1 and E3	Local and remote	*Configuring E1 Loopback Capability* and *Configuring E3 Loopback Capability*
*N*xDS0	Payload	*Configuring Channelized E1 IQ and IQE Interfaces*, *Configuring T1 and NxDS0 Interfaces*, *Configuring Channelized OC12/STM4 IQ and IQE Interfaces (SONET Mode)*, *Configuring Channelized STM1 IQ and IQE Interfaces*, and *Configuring Channelized T3 IQ Interfaces*
Serial (V.35 and X.21)	Local and remote	*Configuring Serial Loopback Capability*
Serial (EIA-530)	DCE local, DCE remote, local, and remote	*Configuring Serial Loopback Capability*
SONET/SDH	Local and remote	*Configuring SONET/SDH Loopback Capability*

Copyright © 2014, Juniper Networks, Inc.

Table 8: Loopback Modes by Interface Type *(continued)*

Interface	Loopback Modes	Usage Guidelines
T1 and T3	Local, payload, and remote	*Configuring T1 Loopback Capability* and *Configuring T3 Loopback Capability* See also *Configuring the T1 Remote Loopback Response*

To configure loopback testing, include the **loopback** statement:

loopback *mode*;

You can include this statement at the following hierarchy levels:

- **[edit interfaces** *interface-name* **aggregated-ether-options]**
- **[edit interfaces** *interface-name* **ds0-options]**
- **[edit interfaces** *interface-name* **e1-options]**
- **[edit interfaces** *interface-name* **e3-options]**
- **[edit interfaces** *interface-name* **fastether-options]**
- **[edit interfaces** *interface-name* **gigether-options]**
- **[edit interfaces** *interface-name* **serial-options]**
- **[edit interfaces** *interface-name* **sonet-options]**
- **[edit interfaces** *interface-name* **t1-options]**
- **[edit interfaces** *interface-name* **t3-options]**

Interface Diagnostics

BERT allows you to troubleshoot problems by checking the quality of links. You can configure any of the following interfaces to execute a BERT when the interface receives a request to run this test: E1, E3, T1, T3; the channelized DS3, OC3, OC12, and STM1 interfaces; and the channelized DS3 IQ, E1 IQ, and OC12 IQ interfaces.

A BERT test requires a line loop to be in place on either the transmission devices or the far-end router. The local router generates a known bit pattern and sends it out the transmit path. The received pattern is then verified against the sent pattern. The higher the bit error rate of the received pattern, the worse the noise is on the physical circuit. As you move the position of the line loop increasingly downstream toward the far-end router, you can isolate the troubled portion of the link.

To configure BERT, you must configure the duration of the test, the bit pattern to send on the transmit path, and the error rate to monitor when the inbound pattern is received.

To configure the duration of the test, the pattern to send in the bit stream, and the error rate to include in the bit stream, include the **bert-period**, **bert-algorithm**, and **bert-error-rate** statements, respectively, at the **[edit interfaces** *interface-name interface-type*-**options]** hierarchy level:

Copyright © 2014, Juniper Networks, Inc.

```
[edit interfaces interface-name interface-type-options]
bert-algorithm algorithm;
bert-error-rate rate;
bert-period seconds;
```

By default, the BERT period is 10 seconds. You can configure the BERT period to last from 1 through 239 seconds on some PICs and from 1 through 240 seconds on other PICs.

rate is the bit error rate. This can be an integer from 0 through 7, which corresponds to a bit error rate from 10^{-0} (1 error per bit) to 10^{-7} (1 error per 10 million bits).

algorithm is the pattern to send in the bit stream. For a list of supported algorithms, enter a **?** after the **bert-algorithm** statement; for example:

```
[edit interfaces t1-0/0/0 t1-options]

user@host# set bert-algorithm ?
Possible completions:
  pseudo-2e11-o152     Pattern is 2^11 -1 (per O.152 standard)
  pseudo-2e15-o151     Pattern is 2^15 - 1 (per O.152 standard)
  pseudo-2e20-o151     Pattern is 2^20 - 1 (per O.151 standard)
  pseudo-2e20-o153     Pattern is 2^20 - 1 (per O.153 standard)
        ...
```

For specific hierarchy information, see the individual interface types.

NOTE: The 4-port E1 PIC supports only the following algorithms:

```
pseudo-2e11-o152     Pattern is 2^11 -1 (per O.152 standard)
pseudo-2e15-o151     Pattern is 2^15 - 1 (per O.151 standard)
pseudo-2e20-o151     Pattern is 2^20 - 1 (per O.151 standard)
pseudo-2e23-o151     Pattern is 2^23 (per O.151 standard)
```

When you issue the help command from the CLI, all BERT algorithm options are displayed, regardless of the PIC type, and no commit check is available. Unsupported patterns for a PIC type can be viewed in system log messages.

Copyright © 2014, Juniper Networks, Inc.

NOTE: The 12-port T1/E1 Circuit Emulation (CE) PIC supports only the following algorithms:

```
all-ones-repeating   Repeating one bits
all-zeros-repeating  Repeating zero bits
alternating-double-ones-zeros  Alternating pairs of ones and zeros
alternating-ones-zeros  Alternating ones and zeros
pseudo-2e11-o152     Pattern is 2^11 -1 (per O.152 standard)
pseudo-2e15-o151     Pattern is 2^15 - 1 (per O.151 standard)
pseudo-2e20-o151     Pattern is 2^20 - 1 (per O.151 standard)
pseudo-2e7           Pattern is 2^7 - 1
pseudo-2e9-o153      Pattern is 2^9 - 1 (per O.153 standard)
repeating-1-in-4     1 bit in 4 is set
repeating-1-in-8     1 bit in 8 is set
repeating-3-in-24    3 bits in 24 are set
```

When you issue the help command from the CLI, all BERT algorithm options are displayed, regardless of the PIC type, and no commit check is available. Unsupported patterns for a PIC type can be viewed in system log messages.

NOTE: The IQE PICs support only the following algorithms:

```
all-ones-repeating   Repeating one bits
all-zeros-repeating  Repeating zero bits
alternating-double-ones-zeros  Alternating pairs of ones and zeros
alternating-ones-zeros  Alternating ones and zeros
pseudo-2e9-o153      Pattern is 2^9  -1 (per O.153 (511 type) standard)
pseudo-2e11-o152     Pattern is 2^11 -1 (per O.152 and O.153 (2047 type)
 standards)
pseudo-2e15-o151     Pattern is 2^15 -1 (per O.151 standard)
pseudo-2e20-o151     Pattern is 2^20 -1 (per O.151 standard)
pseudo-2e20-o153     Pattern is 2^20 -1 (per O.153 standard)
pseudo-2e23-o151     Pattern is 2^23 -1 (per O.151 standard)
repeating-1-in-4     1 bit in 4 is set
repeating-1-in-8     1 bit in 8 is set
repeating-3-in-24    3 bits in 24 are set
```

When you issue the help command from the CLI, all BERT algorithm options are displayed, regardless of the PIC type, and no commit check is available. Unsupported patterns for a PIC type can be viewed in system log messages.

Copyright © 2014, Juniper Networks, Inc.

NOTE: BERT is supported on the PDH interfaces of the Channelized SONET/SDH OC3/STM1 (Multi-Rate) MIC with SFP and the DS3/E3 MIC. The following BERT algorithms are supported:

```
all-ones-repeating            Repeating one bits
all-zeros-repeating           Repeating zero bits
alternating-double-ones-zeros Alternating pairs of ones and zeros
alternating-ones-zeros        Alternating ones and zeros
repeating-1-in-4              1 bit in 4 is set
repeating-1-in-8              1 bit in 8 is set
repeating-3-in-24             3 bits in 24 are set
pseudo-2e9-o153               Pattern is 2^9 - 1 (per 0.153 standard)
pseudo-2e11-o152              Pattern is 2^11 - 1 (per 0.152 standard)
pseudo-2e15-o151              Pattern is 2^15 - 1 (per 0.151 standard)
pseudo-2e20-o151              Pattern is 2^20 - 1 (per 0.151 standard)
pseudo-2e20-o153              Pattern is 2^20 - 1 (per 0.153 standard)
pseudo-2e23-o151              Pattern is 2^23 (per 0.151 standard)
```

Table 9 on page 100 shows the BERT capabilities for various interface types.

Table 9: BERT Capabilities by Interface Type

Interface	T1 BERT	T3 BERT	Comments
12-port T1/E1 Circuit Emulation	Yes (ports 0–11)		• Limited algorithms
4-port Channelized OC3/STM1 Circuit Emulation	Yes (port 0–3)		• Limited algorithms
E1 or T1	Yes (port 0–3)	Yes (port 0–3)	• Single port at a time • Limited algorithms
E3 or T3	Yes (port 0–3)	Yes (port 0–3)	• Single port at a time
Channelized OC12	N/A	Yes (channel 0–11)	• Single channel at a time • Limited algorithms • No bit count
Channelized STM1	Yes (channel 0–62)	N/A	• Multiple channels • Only one algorithm • No error insert • No bit count
Channelized T3 and Multichannel T3	Yes (channel 0–27)	Yes (port 0–3 on channel 0)	• Multiple ports and channels • Limited algorithms for T1 • No error insert for T1 • No bit count for T1

Copyright © 2014, Juniper Networks, Inc.

These limitations do not apply to channelized IQ interfaces. For information about BERT capabilities on channelized IQ interfaces, see *Channelized IQ and IQE Interfaces Properties*.

Starting and Stopping a BERT Test

Before you can start the BERT test, you must disable the interface. To do this, include the **disable** statement at the **[edit interfaces *interface-name*]** hierarchy level:

```
[edit interfaces interface-name]
disable;
```

After you configure the BERT properties and commit the configuration, begin the test by issuing the **test interface *interface-name interface-type*-bert-start** operational mode command:

```
user@host> test interface interface-name interface-type-bert-start
```

The test runs for the duration you specify with the **bert-period** statement. If you wish to terminate the test sooner, issue the **test interface *interface-name interface-type*-bert-stop** command:

```
user@host> test interface interface-name interface-type-bert-stop
```

For example:

```
user@host> test interface t3-1/2/0 t3-bert-start
user@host> test interface t3-1/2/0 t3-bert-stop
```

To view the results of the BERT test, issue the **show interfaces extensive | find BERT** command:

```
user@host> show interfaces interface-name extensive | find BERT
```

For more information about running and evaluating the results of the BERT procedure, see the CLI Explorer.

NOTE: To exchange BERT patterns between a local router and a remote router, include the **loopback remote** statement in the interface configuration at the remote end of the link. From the local router, issue the **test interface** command.

Example: Configuring Bit Error Rate Testing

Configure a BERT test on a T3 interface. In this example, the run duration lasts for 120 seconds. The configured error rate is 0, which corresponds to a bit error rate of 10^{-0} (1 error per bit). The configured bit pattern of **all-ones-repeating** means that every bit the interface sends is a set to a value of 1.

```
[edit interfaces]
t3-1/2/0 {
    t3-options {
        bert algorithm all-ones-repeating;
        bert-error-rate 0;
        bert-period 120;
```

Copyright © 2014, Juniper Networks, Inc.

```
    }
}
```


Copyright © 2014, Juniper Networks, Inc.

PART 5

Index

- Index on page 105

Copyright © 2014, Juniper Networks, Inc.

Copyright © 2014, Juniper Networks, Inc.

Index

Symbols

#, comments in configuration statements....x
( ), in syntax descriptions....x
< >, in syntax descriptions....x
[ ], in configuration statements....x
{ }, in configuration statements....x
| (pipe), in syntax descriptions....x

A

adaptive services interfaces....42
  status information, displaying....42

B

BERT
  configuring interface diagnostics....97
bert-algorithm statement
  usage guidelines....97
bert-error-rate statement
  usage guidelines....97
bert-period statement
  usage guidelines....97
bit error rate test *See* BERT
braces, in configuration statements....x
brackets
  angle, in syntax descriptions....x
  square, in configuration statements....x

C

comments, in configuration statements....x
conventions
  text and syntax....ix
curly braces, in configuration statements....x
customer support....xi
  contacting JTAC....xi

D

documentation
  comments on....xi

E

Ethernet interfaces
  status information, displaying
    Fast Ethernet....50
    Gigabit Ethernet....66

F

family statement....32
Fast Ethernet interfaces
  status information, displaying....50
fast-aps-switch statement....36
font conventions....ix

G

Gigabit Ethernet interfaces
  status information, displaying....66

I

interfaces
  configuration statements....9

L

linktrace
  tracing....92
logical systems
  configuration statements....25
loopback testing....95

M

manuals
  comments on....xi

P

parentheses, in syntax descriptions....x
passive-monitor-mode statement....37

R

receive-options-packets statement....38
receive-ttl-exceeded statement....38

S

show interfaces (Adaptive Services) command....42
show interfaces (Fast Ethernet) command....50
show interfaces (Gigabit Ethernet) command....66
support, technical *See* technical support
syntax conventions....ix

Copyright © 2014, Juniper Networks, Inc.

T

technical support
    contacting JTAC....xi
traceroute ethernet....92
traceroute ethernet command....92

Copyright © 2014, Juniper Networks, Inc.