

## baseline log

---

<b>Syntax</b>	baseline log [ last-reset   <i>time</i> [ utc ] <i>month day year</i> ]
<b>Release Information</b>	Command introduced before JUNOS Release 7.1.0.
<b>Description</b>	Sets a baseline for logging events. To use the current system time, do not enter any options. There is no <b>no</b> version.
<b>Options</b>	<ul style="list-style-type: none"><li>■ last-reset—Causes the router to display log messages generated since the last time the router was reset</li><li>■ <i>time</i>—Time and date after which the router displays messages that are timestamped. To set the time, use the following syntax:  <i>Hour:Minute[:Second]</i>—Current time in 24-hour format; seconds are optional</li><li>■ utc—Indicates that the time entered is UTC (GMT) time; if you do not include this keyword, the router considers the time entered to be local time</li><li>■ <i>month</i>—Name of the month in English</li><li>■ <i>day</i>—Number of the day in the range 1–31</li><li>■ <i>year</i>—Four-digit number of the year</li></ul>
<b>Mode</b>	Privileged Exec

