

qos-profile

Syntax	[no] qos-profile <i>qosProfileName</i>
Release Information	Command introduced before JUNOS Release 7.1.0. Profile Configuration mode added in JUNOS Release 7.2.0. QoS Interface Set Configuration and QoS Interface Superset Configuration modes added in JUNOS Release 9.2.0.
Description	<p>In Global Configuration mode, creates a QoS profile on the router and enters QoS Profile Configuration mode. The no version deletes the QoS profile.</p> <p>In Interface Configuration mode, attaches a QoS profile to an interface. The no version detaches the QoS profile from the interface.</p> <p>In Profile Configuration mode, adds a QoS profile command for use with Service Manager. When the service is activated, the QoS profile is created and attached to the subscriber interface. The no version removes the QoS profile from the profile.</p> <p>In QoS Interface Set Configuration mode, attaches a QoS profile to the QoS interface set. The no version detaches the QoS profile from the interface set.</p> <p>In QoS Interface Superset Configuration mode, attaches a QoS profile to the QoS interface superset. The no version detaches the QoS profile from the interface superset.</p>
Options	■ <i>qosProfileName</i> —Name of the QoS profile
Mode	Global Configuration, Interface Configuration, Profile Configuration, QoS Interface Set Configuration, QoS Interface Superset Configuration
Related Topics	■ Configuring a QoS Profile ■ Attaching a QoS Profile to an Interface ■ Configuring Shadow Nodes ■ Configuring a Basic Parameter Definition for QoS Administrators ■ Creating Parameter Instances ■ Attaching a QoS Profile to an Interface Superset or an Interface Set ■ Creating a QoS Parameter on an Interface Superset or Interface Set

