

radius nas-identifier

Syntax radius nas-identifier *identifierValue*
no radius nas-identifier

Release Information Command introduced before JUNOS Release 7.1.0.

Description Configures the RADIUS client's value for RADIUS attribute 32, NAS-Identifier. The **no** version deletes the NAS-Identifier.

Options ■ *identifierValue*—Number, in the range 1–64 characters; used in the NAS-Identifier attribute for authentication and accounting requests

Mode Global Configuration

