

restricted

Syntax	[no] restricted interface <i>restrictedInterfaceType</i> <i>interfaceSpecifier</i> [<i>atmVpi</i> <i>s-vlanIdValue</i>]
Release Information	Command introduced in JUNOS Release 9.2.0.
Description	Configures an interface superset as restricted to a particular ATM-VPI or S-VLAN ID. The no version deletes the restriction for the interface superset.
Options	<ul style="list-style-type: none">■ <i>restrictedInterfaceType</i>—One of the following restricted interface types: atm-vp, fastEthernet, gigabitEthernet, svlan, tenGigabitEthernet■ <i>interfaceSpecifier</i>—Particular interface; format varies according to interface type; see Interface Types and Specifiers in About This Guide■ <i>atmVpi</i>—Virtual path identifier of this PVC; number in the range 0–255■ <i>s-vlanIdValue</i>—S-VLAN ID number in the range 0–4095
Mode	QoS Interface Superset Configuration
Related Topics	<ul style="list-style-type: none">■ Configuring Interface Supersets for QoS

