

show control-plane policer

- Syntax** show control-plane policer protocol *protocolValue*
- Release Information** Command introduced in JUNOS Release 8.0.0.
- Description** Displays control plane information for a specified protocol or for all protocols.
- Options** ■ *protocolValue*—Name of the protocol
- Mode** Privileged Exec, User Exec
- Related Topics** ■ Monitoring Control Plane Policer Information

