

## show ip dhcp-external statistics

---

**Syntax** show ip dhcp-external statistics [ *delta* ] [ *filter* ]

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Displays statistics for the DHCP external server.

- Options**
- *delta*—Displays baselined statistics
  - *filter*—See Filtering show Commands

**Mode** Privileged Exec

**Related Topics**

- Monitoring DHCP External Server Statistics

