

show ip dhcp-local auth

Syntax	show ip dhcp-local auth { config statistics [delta] } [<i>filter</i>]
Release Information	Command introduced in JUNOS Release 7.1.0.
Description	Displays information about the DHCP local server authentication configuration.
Options	<ul style="list-style-type: none">■ config—Specifies that configuration information is shown■ statistics—Specifies that statistics are shown■ delta—Displays baselined statistics■ <i>filter</i>—See Filtering show Commands
Mode	Privileged Exec
Related Topics	<ul style="list-style-type: none">■ Monitoring DHCP Local Server Authentication Information

