

## show ip dhcp-local

---

**Syntax** show ip dhcp-local

**Release Information** Command introduced in JUNOS Release 7.2.0.

**Description** Displays DHCP local server configuration information, including the status of SNMP traps and client roaming support.

**Mode** Privileged Exec

**Related Topics** ■ [Monitoring DHCP Local Server Configuration](#)

