

## show ip mirror interface

---

**Syntax**    show ip mirror interface [ vrf *vrfName* ] [ *interfaceType* *interfaceSpecifier* ]

**Release Information**    Command introduced before JUNOS Release 7.1.0.

**Description**    Displays information about the interface mirroring configuration of all interfaces, or for a specific interface on which mirroring is enabled.



**NOTE:** This command is deprecated and might be removed completely in a future release. The function provided by this command has been replaced by the **show secure policy-list** command.

---

- Options**
- *vrfName*—Name of the VRF
  - *interfaceType*—Interface type; see Interface Types and Specifiers
  - *interfaceSpecifier*—Particular interface; format varies according to interface type; see Interface Types and Specifiers

**Mode**    Privileged Exec

**Related Topics**    ■    Monitoring the Packet Mirroring Configuration of IP Interfaces

