

## show radius servers

---

<b>Syntax</b>	show radius [ <i>serverType</i> ] servers [ <i>filter</i> ]
<b>Release Information</b>	Command introduced before JUNOS Release 7.1.0. <b>pre-authentication</b> keyword added in JUNOS Release 8.1.0.
<b>Description</b>	Displays information about the RADIUS servers configured on the router.
<b>Options</b>	<ul style="list-style-type: none"><li>■ <i>serverType</i>—One of the following RADIUS server types:<ul style="list-style-type: none"><li>■ authentication—Displays authentication information only</li><li>■ accounting—Displays accounting information only</li><li>■ dynamic-request—Displays dynamic-request information only</li><li>■ pre-authentication—Displays preauthentication information only</li></ul></li><li>■ <i>filter</i>—See Filtering show Commands</li></ul>
<b>Mode</b>	Privileged Exec
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Monitoring RADIUS Dynamic-Request Server Information</li></ul>

