

show terminate-code

Syntax show terminate-code { *application* [*terminateReason* | *translationApplication*] | *translationApplication* [*terminateCode*] } [*filter*]

Release Information Command introduced in JUNOS Release 7.3.0.

Description Displays information about the current mappings of application terminate reasons to standards-based terminate codes.

- Options**
- *application*— Application; AAA, L2TP, PPP, or RADIUS client
 - *terminateReason*—Reason that the subscriber's session was terminated
 - *translationApplication*—Application whose terminate code is used for the mapping; for example, RADIUS
 - *terminateCode*—Code used by the translation application to identify the terminate reason; for example, a RADIUS Acct-Terminate-Cause code
 - *filter*—See Filtering show Commands

Mode Privileged Exec

