

## sscc address

---

**Syntax**    `sscc { primary | secondary | tertiary } address ipAddress [ port portNumber ]`  
`no ssc { primary | secondary | tertiary } address [ ipAddress [ port portNumber ] ]`

**Release Information**    Command introduced before JUNOS Release 7.1.0.

**Description**    Configures the SRC client (formerly SSCC) with the IP addresses of the SRC servers and the ports on which the servers listen for activity. The **no** version removes the specified server (primary, secondary, or tertiary) from the list of SRC servers.

- Options**
- `primary`—Primary SRC server
  - `secondary`—Secondary SRC server
  - `tertiary`—Tertiary SRC server
  - `ipAddress`—IP address of an SRC server
  - `portNumber`—SRC server port number on which the server listens for activity; default port is 3288

**Mode**    Global Configuration

