

vlan id

Syntax	vlan id <i>idValue</i> [untagged] [mac-address <i>macAddress</i>]
Release Information	Command introduced before JUNOS Release 7.1.0.
Description	Specifies a VLAN ID. There is no no version.
Options	<ul style="list-style-type: none">■ <i>idValue</i>—Number unique within the Ethernet interface, in the range 0–4095■ untagged—Specifies that frames be sent untagged; valid only for VLAN ID 0■ <i>macAddress</i>—MAC address of the interface; when you do not specify a unique MAC address, the VLAN uses the MAC address of the Ethernet interface
Mode	Interface Configuration
Related Topics	<ul style="list-style-type: none">■ <i>Configuring Ethernet/VLAN Layer 2 Services, Configuring Local ATM Cross-Connect with AAL5 Encapsulation, and Configuring Local Cross-Connects Between Ethernet/VLAN Interfaces</i> in the <i>JUNOS BGP and MPLS Configuration Guide</i>

