

baseline log

Syntax baseline log [last-reset | *time* [*utc*] *month day year*]

Release Information Command introduced before JUNOS Release 7.1.0.

Description Sets a baseline for logging events. To use the current system time, do not enter any options. There is no **no** version.

- Options**
- last-reset—Causes the router to display log messages generated since the last time the router was reset
 - *time*—Time and date after which the router displays messages that are timestamped. To set the time, use the following syntax:

Hour:Minute[:Second]—Current time in 24-hour format; seconds are optional
 - *utc*—Indicates that the time entered is UTC (GMT) time; if you do not include this keyword, the router considers the time entered to be local time
 - *month*—Name of the month in English
 - *day*—Number of the day in the range 1–31
 - *year*—Four-digit number of the year

Mode Privileged Exec

