

## radius nas-identifier

---

**Syntax** radius nas-identifier *identifierValue*  
no radius nas-identifier

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Configures the RADIUS client's value for RADIUS attribute 32, NAS-Identifier. The **no** version deletes the NAS-Identifier.

**Options** ■ *identifierValue*—Number, in the range 1–64 characters; used in the NAS-Identifier attribute for authentication and accounting requests

**Mode** Global Configuration

