

show ip dhcp-local

Syntax	show ip dhcp-local
Release Information	Command introduced in JUNOS Release 7.2.0.
Description	Displays DHCP local server configuration information, including the status of SNMP traps and client roaming support.
Mode	Privileged Exec
Related Topics	■ Monitoring DHCP Local Server Configuration

