

show license

Syntax show license [*licenseType*] [*filter*]

Release Information Command introduced before JUNOS Release 7.1.0.
 service-management keyword added in JUNOS Release 7.2.0.

Description Displays all licenses or a specified license.



NOTE: The **show license l2tp-session** command remains in the CLI even though a separate L2TP license is no longer required to enable support for 32,000 L2TP sessions on supported systems.

- Options**
- *licenseType*—bfd, b-ras, ipsec-tunnels, ipv6, l2tp-session, nat, or service-management
 - *filter*—See Filtering show Commands

Mode Privileged Exec

