

## show radius attributes-included

---

**Syntax** show radius attributes-included [ *filter* ]

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Displays the RADIUS attributes that are included in and excluded from Access-Request, Acct-Start, and Acct-Stop messages. You configure attribute inclusion using the **radius include** commands.

**Options** ■ *filter*—See Filtering show Commands

**Mode** Privileged Exec

