

qos-interface-superset

Syntax [no] qos-interface-superset *interfaceSupersetName*

Release Information Command introduced in JUNOS Release 9.2.0.

Description Configures a QoS interface superset and enters QoS Interface Superset Configuration mode. The **no** version deletes the interface superset.

Options ■ *interfaceSupersetName*—Name of the QoS interface superset

Mode Global Configuration

Related Topics ■ Configuring Interface Supersets for QoS

