

## vlan id

---

<b>Syntax</b>	vlan id <i>idValue</i> [ untagged ] [ mac-address <i>macAddress</i> ]
<b>Release Information</b>	Command introduced before JUNOS Release 7.1.0.
<b>Description</b>	Specifies a VLAN ID. There is no <b>no</b> version.
<b>Options</b>	<ul style="list-style-type: none"><li>■ <i>idValue</i>—Number unique within the Ethernet interface, in the range 0–4095</li><li>■ untagged—Specifies that frames be sent untagged; valid only for VLAN ID 0</li><li>■ <i>macAddress</i>—MAC address of the interface; when you do not specify a unique MAC address, the VLAN uses the MAC address of the Ethernet interface</li></ul>
<b>Mode</b>	Interface Configuration
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ <i>Configuring Ethernet/VLAN Layer 2 Services, Configuring Local ATM Cross-Connect with AAL5 Encapsulation, and Configuring Local Cross-Connects Between Ethernet/VLAN Interfaces</i> in the <i>JUNOS BGP and MPLS Configuration Guide</i></li></ul>

