

show l2tp destination profile

Syntax show l2tp destination profile [*profileName*] [*filter*]

Release Information Command introduced before JUNOS Release 7.1.0.

Description Displays destination profile configuration.

- Options**
- *profileName*—Name of a profile
 - *filter*—See Filtering show Commands

Mode Privileged Exec

