

ip vrrp enable

Syntax [no] ip vrrp *vrid* [enable]

Release Information Command introduced before JUNOS Release 7.1.0.

Description Enables a VRID. The **no** version disables a VRID. The default is disabled.

Options ■ *vrid*—VRID identifier; a number in the range 1–255

Mode Interface Configuration

Published: 2009-10-09