

## peak-burst

---

**Syntax** peak-burst *size* { millisecond *milliseconds* }  
no peak-burst

**Release Information** Command introduced before JUNOS Release 7.1.0.  
*milliseconds* variable added in JUNOS Release 8.1.0.

**Description** Sets the peak burst for a rate-limit profile. The **no** version restores the default value, 100 ms; if 100ms is less than 8K, then 8K (8192).

- Options**
- *size*—Size in bytes in the range 1–4294967295
  - *milliseconds*—Milliseconds in the range 1–10000

**Mode** Rate Limit Profile Configuration

**Related Topics** ■ Creating a Two-Rate Rate-Limit Profile

---

Published: 2009-10-08