

## radius remote-circuit-id-delimiter

---

**Syntax**    radius remote-circuit-id-delimiter *delimiter*  
              no radius remote-circuit-id-delimiter

**Release Information**    Command introduced before JUNOS Release 7.1.0.

**Description**    Specifies the delimiter character that sets off components in the PPPoE remote circuit ID value sent from a DSLAM and captured on the router. The **no** version restores the default delimiter character, #.

**Options**    ■    *delimiter*—Special character (for example, ! or %) to set off components in the PPPoE remote circuit ID value captured from a DSLAM; the default delimiter character is #

**Mode**    Global Configuration

---

Published: 2009-10-08