

## show aaa intf-desc-format

---

**Syntax** show aaa intf-desc-format

**Release Information** Command introduced before JUNOS Release 7.1.0.

**Description** Displays whether the router includes or excludes the subinterface number and adapter in the interface description that the router passes to RADIUS for inclusion in the NAS-Port-Id attribute

**Mode** Privileged Exec

---

Published: 2009-10-08