

show icr-partitions

Syntax show icr-partitions [*brief*] [*filter*]

Release Information Command introduced in JUNOS Release 10.3.0.

Description Displays a list of all configured ICR partitions. Includes information about the state of the partition, the partition identifier, the virtual router identifier, and the interface identifier.

- Options**
- *brief*—Displays a brief summary of each ICR partition entry
 - *filter*—See Filtering show Commands

Mode Privileged Exec

- Related Topics**
- Monitoring the Configuration of ICR Partitions
 - Monitoring the Configuration of an ICR Partition Attached to an Interface
 - Monitoring the Status of ICR Partition Accounting

Published: 2009-10-08