

show ipv6 dhcpv6-local prefix-lifetime

| | |
|----------------------------|--|
| Syntax | show ipv6 dhcpv6-local prefix-lifetime [<i>filter</i>] |
| Release Information | Command introduced before JUNOS Release 7.1.0. |
| Description | Displays the DHCPv6 default prefix lifetime. |
| Options | ■ <i>filter</i> —See Filtering show Commands |
| Mode | Privileged Exec |
| Related Topics | ■ Monitoring DHCPv6 Local Server Prefix Lifetime |

Published: 2009-10-09